

Pro Tips

- Center your protein on the spit rod for smooth, even rotation.
- Tie wings and legs with butcher's twine to keep them secure.
- Use less charcoal and bank it to the back when cooking lid-open.
- Don't exceed 600°F — high heat can damage silicone pads.
- Use a USB-A battery pack for portable cooking. If a USB-C to USB-C cable is used, some USB-C power sources may not work with the motor.