



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

722937
End Table

ITEM: **722937**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION

A TOP



1PC


B LEG FRAME



2PCS

HARDWARE IDENTIFICATION

1 BOLT WITH WASHER
(M6 x 50mm - BLK)



6PCS

2 ALLEN WRENCH
(M4 x 55mm - GD)



1PC


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **722937**

ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2 COMPLETE



ITEM: **722937**



Note: Dimension tolerance $\pm 5\%$