

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

930276 SIDE TABLE

ITEM: 930276

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.

2. Please check to see that all hardware and parts are present prior to start of assembly.

3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION



HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 15g		1 PC	4	CAM LOCK Ø15x12mm SR		6 PCS
2	WOODEN DOWEL Ø8x30mm		8 PCS	5	STICKER Ø20mm		1 PC
3	CAM BOLT Ø7x35.5mm SR		6 PCS	6	PLASTIC GASKET		4 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM:930276 STEP 1















2


STEP 2












ITEM: 930276 STEP 3











STEP 4












ITEM:930276

STEP 7

COMPLETE














Note: Dimension tolerance ±5%