

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

701024
TV CONSOLE

ITEM:701024



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

40 MINUTES

MAX TV SIZE: 65"


PARTS IDENTIFICATION

A LEFT SIDE
PANEL



1 PC

B RIGHT SIDE
PANEL




1 PC

C LEFT DIVIDE
PANEL




1 PC

D RIGHT DIVIDE
PANEL




1 PC

E BOTTOM PANEL




1 PC

F CROSS BRACE




2 PCS

G CROSS PANEL




1 PC

H TOP PANEL




1 PC

I UPPER BACK
PANEL




1 PC

J DOWN BACK
PANEL




1 PC

K DRAWER
FRONT PANEL



2 PCS

L DRAWER BACK
PANEL




2 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:701024














M LEFT DRAWER SIDE PANEL  2 PCS

O DRAWER BOTTOM PANEL  2 PCS

N RIGHT DRAWER SIDE PANEL  2 PCS

Z

HARDWARE IDENTIFICATION

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	8	GLIDES L = 350mm		2 SET
2	WOODEN DOWEL Ø 8x30mm		42 PCS	9	GLIDES SCREW Ø 3x12mm		24 PCS
3	CAM BOLT Ø 7x35.5mm		20 PCS	10	HANDLE		2 PCS
4	CAM LOCK Ø15x12mm		20 PCS	11	HANDLE BOLT M5x25mm		4 PCS
5	SCREW Ø 4.5x42mm		4 PCS	12	NUT M5		4 PCS
6	DRAWER SCREW Ø 4.3x35mm		8 PCS	13	STICKER Ø 20mm		4 PCS
7	PLASTIC FEET Ø 15mm		6 PCS				

Z8,Z10,Z11,Z12 not included in blister packaging.






NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: 701024

STEP 1

COASTER
FINE FURNITURE



INCORRECT
CORRECT





Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM: 701024



COASTER
FINE FURNITURE

STEP 2

Apply glue on all wooden dowels to ensure integrity of the structure.



STEP 3





Apply glue on all wooden dowels to ensure integrity of the structure.


ITEM: 701024

STEP 4



COASTER
FINE FURNITURE



Apply glue on all wooden dowels to ensure integrity of the structure.




STEP 5




ITEM: 701024

STEP 6




STEP 7




ITEM: **701024**

COASTER
FINE FURNITURE

STEP 8




STEP 9




ITEM: **701024**


STEP 10-1




STEP 10-2




STEP 10-3



STEP 10-4




STEP 10-5





ITEM: **701024**

STEP 11





STEP 12

COMPLETE



ITEM: 701024



Note : Dimension tolerance $\pm 5\%$

*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

707726
MEDIA TOWER

ITEM:707726

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!













1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

50 MINUTES

PARTS IDENTIFICATION

















A	LEFT SIDE PANEL		1 PC	G	UPPER CROSS PANEL		2 PCS
B	RIGHT SIDE PANEL		1 PC	H	TOP PANEL		1 PC
C	FRONT CROSS BRACE		1 PC	I	UPPER BACK PANEL		3 PCS
D	BOTTOM PANEL		1 PC	J	LOWER BACK PANEL		1 PC
E	ADJUSTABLE SHELF		1 PC	K	DOOR		1 PC
F	LOWER CROSS PANEL		1 PC	L	BACK CROSS BRACE		1 PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:707726

HARDWARE IDENTIFICATION**Z**

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	9	HANDLE BOLT M5x25mm BLK		2 PCS
2	WOODEN DOWEL ø8x30mm		28 PCS	10	NUT M5		2 PCS
3	CAM BOLT ø7x35.5mm SR		16 PCS	11	HINGE ø35mm SR		2 PCS
4	CAM LOCK ø15x12mm SR		16 PCS	12	HINGE SCREW ø4x15mm SR		8 PCS
5	PLASTIC FEET Ø15mm		4 PCS	13	FIXER		6 PCS
6	PIN FOR ADJUSTABLE SHELF ø4.9x8mm SR		4 PCS	14	FIXER SCREW ø3x19mm SR		6 PCS
7	DOOR CATCH		1 PC	15	SCREW Ø4.5x42mm SR		4 PCS
8	HANDLE BLK		1 PC	16	STICKER ø20mm		3 PCS

Z8,Z9,Z10,Z11 not included in blister packaging.

NOTE:



Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **707726**

STEP 1







FINE FURNITURE



ITEM: **707726**

STEP 2

COASTER
FINE FURNITURE






Apply glue on all wooden dowels to ensure integrity of the structure.


ITEM: 707726

STEP 3

COASTER
FINE FURNITURE



STEP 4





Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM: **707726**



STEP 5

COASTER
FINE FURNITURE



Apply glue on all wooden dowels to ensure integrity of the structure.



STEP 6






ITEM: **707726**

STEP 7

COASTER
FINE FURNITURE



STEP 8






ITEM: **707726**



STEP 9

LEFT

COASTER
FINE FURNITURE





RIGHT





ITEM: 707726

STEP 10

COASTER
FINE FURNITURE






RIGHT



HORIZONTAL BY
SCREW A ADJUSTMENT

LATERAL BY
SCREW B ADJUSTMENT




VERTICAL BY
SCREW C ADJUSTMENT






ITEM: **707726**

STEP 11


COASTER
FINE FURNITURE



STEP 12



ITEM: 707726



Note : Dimension tolerance $\pm 5\%$

ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture
may result in injury and damage.

1. To attach the anti-tip strap, securely mount one end to the top of the case piece with the 5/8" screw.
2. Position the case piece against the wall in the desired location.
3. Pull the anti-tip strap taut and mark the position of where you will secure the other end on the wall.
4. Drill a 1-1/4" hole in the spot you marked.
5. Tap in plastic wall plug.
6. Fasten anti-tip strap with wall screw provided.

(Please install the anti-tipping kit in the middle of the case piece if only have one set of anti-tipping kit.)

