# avar

## SmartMediaPro (SSP-0600) **Quick Reference Guide**

The Savant SmartMediaPro (SSP-0600) Quick Reference Guide provides information necessary to install the SSP-0600, a modular A/V matrix switcher and controller. SSP-0600 is ideal for installations requiring high definition (HD) video switching and audio switching.

#### **Box Contents**

(1) SmartMediaPro (SSP-0600)

- (1) Installation Kit (075-0098-xx)
  - (4) M5 x 8mm Flat Phillips Screw (039-0180-xx)

  - (2) 9-pin Screw Down Plug-In Connector (028-9353-xx)
    (2) 6-pin Screw Down Plug-in Connector (028-9352-xx)
    (1) Power cord C13 (6 feet) (N. America) (064-0079-xx) or appropriate international (1) Power cord
     (1) Mini Display Port to HDMI Cable (1 meter) (064-0222-xx)
     (2) Module Removal Tool (071-0268-xx)
     (2) Rack Mounting Bracket (3U) (071-0638-xx)
     (1) HDMI Locking Cable (3 ft) (CBL-3LHDMI-xx)
     (1) HDMI Locking Cable (3 ft) (CBL-3LHDMI-xx)

(1) Quick Reference Guide (this document)

### Specifications

Environmental	
Temperature	32° to 104° F (0° to 40° C)
Humidity	10% to 80% RH (non-condensing)
Cooling	25 cubic feet per minute (CFM) recommended.
-	Note that each chassis has fans pushing 36 CFM.
Maximum BTUs	512 BTUs per hour
Noise	Normal Operation condition: 52 dB Average
Dimensions and Weight	
Dimensions (H x W x D)	5.21 in x 17.30 in x 14.16 in (13.23 cm x 43.94 cm x 35.96 cm)
Weight	24.91 lb/11.3 kg (Base Configuration)
Rack Space	3U
Power	
Power Supply	100 – 240V AC 50/60 Hz
Maximum Power	200 Watts
Compliance	
Safety and Emissions	S-Mark/FCC Part 15/CE Mark/C-Tick/CB
DollS	Compliant

#### Front Panel



The	The next table describes the functionality on the front of an SSP-0600.						
1	Power LED Green indicates the system has adequate power and is						
		operating normally.					
		Red indicates the system is in stand-by mode. The Controller					
		hardware has power, but the embedded processor is shut off					
		and in the standby mode.					
		Off indicates that the system is not receiving power.					
2	Standby Power (hole)	Insert pin into hole for about 5 seconds to place in standby					
		mode. Insert the pin again for about 5 seconds to take					
		system out of standby mode. To turn the power off for the					
		entire system, use the switch on the rear panel.					
3	Status LED	Green indicates the Host has evaluated the firmware					
		currently running and determined it is up to date.					
		Green flashing indicates the embedded system is ready					
		(running with DHCP IP address), but the embedded					
		processor has not established communications with the					
		embedded system.					
		Off indicates the embedded processor is resetting or is					
		powered up; and is booting the embedded firmware.					
		Red indicates the Host has determined the firmware needs to					
		be updated, but a problem occurred during the process that					
		Will Initiate a reset.					
		Red flashing indicates the embedded firmware is running,					
		Amber indicates the Heat is currently undefind the					
		ambedded firmware					
		Amber flashing indicates the embedded system has a valid					
		link local ID Address and is waiting to connect to the Heat					
		Over Temperature or Hardware Failure					
		If the Controller overheats or has a hardware failure, the					
		Status I ED indication will be interrunted every 3-seconds					
		with a solid red indication. For example, if the LED is flashing					
		green when an over temperature or hardware failure occurs					
		the LED, in 3-second intervals, will flash green, solid red, etc.					
4	Video I ED	Off indicates the encrypted video content remains protected					
1 -		The HDCP keys remain valid					
		<b>Red flashing</b> indicates the HDCP keys are invalid.					
5	FanlED	Groop indicates the face are operating					

		Off indicates the fans are not operating.				
9	Video Port LED	Off indicates which video output port(s) do not have an error.				
		Green indicates which video output port(s) have an error.				
7	Relay LEDs	Green indicates activity on the associated ports on the rear				
8	RS-232 LEDs	of the unit.				
9	IR LEDs	Off indicates no activity on the associated ports on the rear				
10	GPIO LEDs	of the unit.				

#### Rear Panel



10

The next table describes the functionality on the rear of an SSP-0600

1	Reset Button	Resets the SSP-0600			
2	Host Audio 1, 2	HDMI input ports used to receive digital			
		audio (iTunes®) from host.			
3	Ethernet	RJ45 10/100 Base-T, auto-negotiating port			
4	RS-232/422/485 (serial ports 1 – 8)	RJ45 ports used to transmit and receive			
		serial binary data transmission. Ports 1			
		and 2 support flow control Clear to Send /			
		Ready to Send (CTS/RTS) for RS-232.			
5	IR Output (1 – 6)	Infrared transmitter output ports			
6	Relay 1, 2, 3 NC/C/NO (Normally	These ports provide dry contacts			
	Closed/Common/Normally Open)	(open/closed) to control devices requiring			
		basic on/off operation.			
7	Input power connector	100-240V AC, 50/60 Hz source power to			
		controller from a surge-protected circuit.			
8	I/O	On/Off button,			
		<ul> <li>I to power the controller to the On state.</li> </ul>			
		<ul> <li>O to power the controller to the Off state.</li> </ul>			
9	Fuse 250V	5 Amp fast acting fuse			
10	GPIO COM, 1 – 7, COM	General Purpose Input and Output ports			
		The digital GPIO ports are binary I/O ports			
		used for output or input. Each GPIO is			
		individually configured as an input or			
		output trigger. All seven GPIO pins use the			
		COM pins for common ground (at each			
		end of the GPIO block).			
	GPIO Inputs	When configured as an input, the GPIO			
		port detects a voltage present (GPIO			
		input). GPIO inputs can safely detect the			
		presence of a voltage of 0-30V DC with a			
		threshold of 2.4V DC.			
	GPIO Outputs	When configured as an output, the GPIO			
		port outputs a voltage is 12V DC. The			
		maximum current per port is 150			
		milliamps. The combined maximum			
		current for all GPIO outputs is 550			
	1	milliamos			

Audio and Video Module Slot Information



Important: Before adding any modules to the SSP-0600, remove power from the SSP-0600 chassis by setting the power switch to Off (O) on the rear panel and removing the AC power cord. Failure to do so will result in damage to the equipment.

The audio and video module slots as shown on the previous image of the rear panel are categorized as follows:

- The top three slots (1-3) only accept audio and video input modules.
- The bottom three slots (4-6) only accept audio and video output modules.

#### **Grounding Procedure**

To avoid damage from electrostatic discharge (ESD) when handling modules, use a grounding strap as shown below:



Observe the following precautions to prevent ESD discharge damage:

- Use an approved ESD wrist or ankle-grounding strap. Ensure the grounding strap 1. makes good skin contact.
- 2. Before installing or removing a Savant module, connect the clip end of the ground strap to a grounded surface.

Copyright © 2012 Savant Systems LLC, SAVANT and RacePoint Blueprint are trademarks of Savant Systems, LLC All brand names, product names and trademarks are the property of their respective owners. Savant Systems, LLC reserves the right to change product specifications without notice.

Savant Confidential and Proprietary

45 Perseverance Way, Hyannis, MA 02601 Phone 508.683.2500 Fax 508.683.2600 www.SavantSystems.com



If you plan to return a replaced module to Savant Systems LLC, place it in the clamshell package that it was originally shipped in or a static shielding bag to avoid ESD damage to the card

NOTE: The wrist strap only protects the component from ESD voltages on the body; ESD voltages on clothing can still cause damage.

#### Wiring and Connectors

#### **RS-232 Wiring**

#### Controller RJ-45 (RS-232) Plug Pinouts



1 (Not Used for RS-232)	5 RXD (RS-232)
2 (Not Used for RS-232)	6 TXD for (RS-232)
3 (Not Used for RS-232)	7 CTS (RS-232) ports 1 and 2 only
4 GND (RS-232)	8 RTS (RS-232) ports 1 and 2 only

#### RS-422/485 Pinouts

Controller RJ-45 (RS-422/RS-485) Plug Pinouts



1 RX+ (RS-422/485)	5 (Not Used for RS-422/485)
2 RX- (RS-422/485)	6 TX- (RS-422/485)
3 TX+ (RS-422/485)	7 (Not Used for RS-422/485)
4 GND (RS-422/485)	8 (Not Used for RS-422/485)

🚹 Important

If you are using RJ-45 to DB-9 adapters not supplied by Savant, be sure to terminate any wires required for communication/control within the adapter. Ensure that all wires required for communication/control are not terminated in the connecter. Also, ensure that the unused wires in the connector are cut to prevent them shorting out, as they are still terminated in the RJ-45 connector on the controller side.

For more details on RS-232, RS-422 and RS-485 connectors, go to SavantSystems.com >Dealer Login > Knowledge Base > Products

Refer to the RS-232/RS Conversion to DB-9, and RS-422/485 Pinout Application Note

IR Port Layout and Pinouts (two 6-pin 3.81mm screw down connectors)

1		2	2	3		
-	+	-	+	-	+	
4		5		6		
-	+	-	+	-	+	

#### Relay and GPIO Port Pinouts (9-pin 3.81mm screw down connectors)

Relay 1			Relay 2			Relay 3			
NC	С	NO	NC C NO		NC	С	NO		
GPIO									
COM	1	2	3	4	5	6	7	COM	

#### Interconnect the Network

The SSP-0600 Controller requires business class/commercial grade network equipment in order to handle the IP traffic between Savant Network Equipment. When configuring the network ensure that all of the connected Savant units (SSP-0600 Controller, host, etc.) are on the same local area network (subnet or LAN). Being on the same subnet allows the Savant units to locate each other using the Bonjour® network protocol.

#### Network Changes Require Rebooting the SSP-0600 Controller

The embedded processor used in the SSP-0600 Controller, needs to be rebooted after switching to a new network with a new IP address range. If you do not reboot, the Controller will not sense the network and IP address changes. The **Status** LED on the front panel of the Controller will start to flash. Logs will be reported in System Monitor.

#### **Replacing or Checking Fuse**

#### ELECTRIC SHOCK: The 100-240V AC, 50-60 Hz source power poses an electric shock hazard that has the pote al to cause serious injury to installers and end-users. Before replacing the fuse, turn the SSP-0600 off and remove the AC power cord.

#### To replace or check the fuse on the SSP-0600, do the following:

On the input power block, open the cover (hinged) to access the fuse cartridge. Refer to 1 the illustrations below.





Important: Before removing the fuse, note how and where the fuse is mounted in the cartridge. The fuse must be replaced at the same location. Refer to the illustrations below

- 3. Remove the 250V, 5A fuse and replace with a new one
- 4 Re-install the cartridge. Note that the cartridge fits in only one direction.



#### **Restoring System Defaults**

This procedure will clear a static IP address, which has been set up in the embedded scanner, RPMembscanner— a Savant specific program located in the RacePoint Blueprint™ folder and installed when you load RacePoint Blueprint™ on your computer.

To restore the default state of the SSP-0600 do the following

Using a wire (for example, a strand from a Cat-5 cable), connect IR 1+ to GPIO 1. See the next figure



- 2. Power up or reset the system.
- 3. The status LED will blink green briefly while the firmware clears the static IP address.
- The system will then reboot and come back up with the status LED blinking green, if the system received an IP address from the DHCP server. If the system has a self-assigned 4. address, the LED is blinking amber.

You can confirm your embedded processor has an IP address by opening the Embedded Scanner window from RacePoint Blueprint<sup>™</sup> by entering *rpmembscanner* in Spotlight. For more information on the embedded scanner, access the dealer portal described in the last section

#### Additional Documentation

Additional documentation for the SSP-0600 is available at: SavantSystems.com and navigate as follows:

- >Dealer Login > Knowledge Base > Products
- Refer to the Savant SmartMediaPro (SSP-1200/1200R & SSP-0600) Deployment Guide for additional installation and configuration information
- Refer to the GPIO Hardware Setup Guide for information on input and output triggers and GPIO input and outputs to Savant Controllers. Refer to the RacePoint Blueprint<sup>™</sup> Programming Guide to configure the SSP-0600
- into a Savant System.

Copyright © 2012 Savant Systems LLC, SAVANT and RacePoint Blueprint are trademarks of Savant Systems, LLC All brand names, product names and trademarks are the property of their respective owners. Savant Systems, LLC reserves the right to change product specifications without notice.