


WARNING	Electrical Shock Hazard
Death or serious injury can result from failure to follow these instructions.	
<ul style="list-style-type: none"> Service by a qualified service technician only. Disconnect power before servicing this product. Reconnect all grounding devices after service. Replace all parts and panels before operating. 	

AVERTISSEMENT	Risque de choc électrique
Vous pouvez être tué ou gravement blessé si vous ne suivez pas ces instructions.	
<ul style="list-style-type: none"> Réparations seulement par un technicien qualifié. Débranchez l'alimentation électrique avant la réparation. Rebranchez tous les dispositifs de mise à la terre après la réparation. Remettez toutes les pièces et panneaux en place avant d'utiliser l'appareil. 	


ADVERTENCIA	Riesgo de Descarga Eléctrica
Usted puede morir o sufrir lesiones graves si no siguen estas instrucciones.	
<ul style="list-style-type: none"> El servicio técnico sólo debe ser realizado por un técnico calificado. Desconecte el suministro de corriente antes de realizar el servicio técnico. Luego del servicio técnico, vuelva a conectar todos los dispositivos de conexión a tierra. Reemplace todas las piezas y paneles antes de utilizar. 	

WATER LEVEL SWITCH
BEFORE DISCONNECTING HOSE FROM WATER LEVEL SWITCH, BE SURE WATER LEVEL IN MACHINE IS BELOW BOTTOM OF WASH BASKET. AFTER RECONNECTING HOSE, PUT MACHINE IN SPIN FOR AT LEAST ONE MINUTE BEFORE CHECKING OPERATION OF SWITCH.


① To Remove Control Panel:
1. Open the lid and remove the two screws from one side of the lid, hold the hinge and slide the lid to pull it out from the washer.




2. Remove the 3 screws from the front of the control panel, be careful do not fall the screws in the basket.




3. Remove the 7 screws from the back side of the cover and remove the back panel. Then remove the two screws from the top rear corners of the control panel.



4. Do not push back the control panel and do not roll it toward the rear to avoid damage, carefully find the pressure sensor tube.



5. With one hand hold the control panel and with the other hand disconnect the pressure sensor tube from the control board turn it to the left and pull it outside.



6. With one hand holding the backplash, with the other holding the hose pressure switch with your thumb and forefinger and turn it to the left and out.

WARNING - Pressure switch hose must not be manipulated either vertically or horizontally as there is a risk of damage to the switch, it must move ONLY as indicated in step 6.

② To Remove Lid:

• Open the lid, remove the four screws (two each side) and lift the lid up to remove.


Left Side	Rid
4. Disconnect the internal drain hose assembly from the cabinet.	

5. Disconnect the rod and spring assemblies from the tub by leaning the washer over enough to slide prop blocks under the belt protector. Bring the washer to the upright position. This will cause the tub assembly to raise up high enough to disengage the rod and spring assemblies from the tub.

③ To Remove Top Cover:

1. Complete previous component removals ① and ②.
2. Remove two 1/4" hex head screws at the rear of the top cover.
3. Slide the harness grommet out toward the rear of the washer.
4. Disengage the power cord from the top cover by lifting up on the front part of the cord and then slide forward to remove.
5. Raise the rear of the top cover up and pull forward slightly to disengage the top cover.

⑤ To Remove Tub and Basket Assembly (Continued):
6. Raise the cabinet up and over the tub assembly.



⑥ To Remove and Install Platform and Transmission Assembly (Continued):
4. Remove eight 3/8th hex bolts that secure the platform transmission assembly to the tub bottom.

Entry into Consumer Error Mode
• From on idle state only (all LEDs off), press and hold Start button for 10 seconds.

• After holding **Start** for 10 seconds, all LEDs will turn on, signifying the user may release the **Start** button.

Behaviors While In Consumer Error Mode

• The **Pause** and **Lid Locked** LEDs should be constantly blinking while in CEM.

• The first fault, if present, will show on the display.

• Pressing **Start** will display the next fault code.

- Models without 7-segment display: Fault code will blink in binary - the consumer will report which LEDs are blinking and which are not. See **Binary Display Fault Chart**

- Models with 7-segment display: Fault code will blink on the 7-segment display.

• At the end of the fault list or if no faults present:

- Models without 7-segment display: All status LEDs will blink.

- Models with 7-segment display: 7-segment display will blink “-”.

Exiting Consumer Error Mode

• Pressing any button (other than **Start**) or turning any knob will exit Consumer Error Mode.

• Consumer Error Mode will time out after 10 minutes

Field Service Mode Entry

From an idle state only (all LEDs off), press and hold **Start** button while rotating the cycle selection knob 180 degrees (7 clicks) and then release the **Start** button.

• Once service mode is entered all LEDs will be flashing.

- On 7-segment display models: (0) will be displayed for Test (0).

- On models without a 7-segment display: All of the status LEDs above the cycle knob will be lit.

• The cycle selection Knob is now used to control the test selection menu.

- Rotating the knob clockwise will increment the test numbers in the display.

- Rotating the knob counter clockwise will decrement the test number in the display.

- Models without 7-segment display: Will display tests using the status lights above the cycle knob in a binary format. (See **Binary Chart**)

- Turning the knob to go to a different test will terminate any current active state.

• Once the test number is selected, pressing **Start** will begin the selected test.

Exit Field Service Mode

• Field service mode will time out after 30 minutes if there is no user activity.

• Models without 7-segment display: Press and hold the **Start** button for 3 seconds





• Models with a 7-segment display: Press **Power** button

Once the washer is in Service Mode, the following service features are available via the cycle knob (on some models):

Knob Index / Test number (Displayed on SSD, 7-segment display, if present) (Without SSD will be displayed in binary format. See Binary Chart)	Test Name	Description of test
0	All LED's on	If tests call for numbers to be shown it will: Display on SSD, 7-segment display, if present. (Without SSD will be displayed in binary format. (See Binary Chart) Turning the cycle knob will index to the next or prior test.
1	Fault Codes	Models without 7-segment display: Faults will be shown: - On Start button press, blink first fault code in binary. (See Binary Chart) - On next Start button press, blink next fault code. - At end of list OR if no fault codes are present, blink all LEDs. - Pressing Start at the end of the fault list will wrap back around. - Use the fault sequence. 7-segment display models: On Start button press, blink first fault code. Display fault code in SSD. At end of list OR if no fault codes are present, washer will flash “-”.
2	Personality ID	Pressing Start will start the test. Flash the set personality after pressing Start . Models without SSD use binary to show personality. Model with SSD will display personality. (See Personality ID Chart for the correct ID for the model being checked.)
3	UI Software Version (Critical)	After entering this test, press the Start button to toggle through the software version number as follows: Example: v0.1.23 High end UI 1st press - "01" on 7SD 2nd press - "23" on 7SD Low end UI (See Version Diagram below) Major version (Pause LED ON)
(Critical)		After entering this test, press the Start button to toggle through the software version number as follows: Example: v0.1.23 High end UI 1st press - "01" on 7SD 2nd press - "23" on 7SD Low end UI (See Version Diagram below) Major version (Pause LED ON)
4	UI Software Version (Non-critical)	After entering this test, press the Start button to toggle through the software version number as follows: Example: v0.1.23 High end UI 1st press - "01" on SSD 2nd press - "23" on SSD Low end UI (See Version Diagram below) Major version (Pause LED ON)
5	XML Version (Non-critical)	Example: v0.1.23 High end UI 1st press - "01" on SSD 2nd press - "23" on SSD Low end UI (See Version Diagram below) Major version (Pause LED ON)
6	Hot Water Valve	Pressing Start will toggle the hot water valve on and off. Test will have a timeout for how long valve will be on (1 minute). The valve will turn off when the test is exited.
7	Cold Water Valve	Pressing Start will toggle the cold water valve on and off. Test will have a timeout for how long valve will be on (1 minute). The valve will turn off when the test is exited.
8	Fabric Softener Dispenser	Pressing Start will toggle the fabric softener valve on and off. Test will have a timeout for how long valve will be on (1 minute). The valve will turn off when the test is exited.
9	Spray Rinse Valve Check	Pressing Start will toggle the spray rinse valve on and off. Test will have a timeout for how long valve will be on (1 minute). The valve will turn off when the test is exited.
10	Pressure Sensor	Pressing Start will start the test. Pressure sensor test will have a timeout. All valves will turn on. All LEDs will blink at start of test. Stop blinking LEDs as approximate water levels are crossed. The

Binary Display Fault Chart		
Fault/Test # displayed on 7-segment display	When entered into service mode	Fault/Test # displayed in binary format using cycle status lights
		Service Mode Tests Filled circles indicate light on
0	All LEDs on	● ● ● ● ●
1	Fault Codes	○ ○ ○ ○ ○
2	Personality ID	○ ○ ○ ○ ● ○
3	UI Software Version (Critical)	○ ○ ○ ○ ● ○
4	UI Software Version (Non-critical)	○ ○ ○ ○ ● ○
5	XML Version (Non-critical)	○ ○ ○ ○ ● ○
6	Hot Water Valve	○ ○ ○ ○ ● ○
7	Cold Water Valve	○ ○ ○ ○ ● ○
8	Fabric Softener Dispenser	○ ○ ○ ○ ● ○
9	Spray Rinse Valve	○ ○ ○ ○ ● ○
10	Pressure Sensor	○ ○ ○ ○ ● ○
11	Recirculate Pump	○ ○ ○ ○ ● ○
12	Drain Pump	○ ○ ○ ○ ● ○
13	Lid Switch	○ ○ ○ ○ ● ○
14	Spin	○ ○ ○ ○ ● ○
15	Agitate	○ ○ ○ ○ ● ○
16	Clear all F Codes	○ ○ ○ ○ ○ ○
17	Change Personality	○ ○ ○ ○ ○ ○
18	Analog Knob	○ ○ ○ ○ ○ ○
19		○ ○ ○ ○ ○ ○
20		○ ○ ○ ○ ○ ○
21		○ ○ ○ ○ ○ ○
22		○ ○ ○ ○ ○ ○
23		○ ○ ○ ○ ○ ○
24		○ ○ ○ ○ ○ ○
25		○ ○ ○ ○ ○ ○

Binary Format		
Model	Personality Number	Service Part Number Filled Circles Indicate light on
MTW201	5	WW01F02068 ○ ○ ○ ○ ● ○
GTW223	4	WW01F02068 ○ ○ ○ ○ ○ ○
GTW302	6	WW01F01907 ○ ○ ○ ○ ● ○
GTW331	3	WW01F02068 ○ ○ ○ ○ ● ○
GTW334	3	WW01F02068 ○ ○ ○ ○ ● ○
GTW451	2	WW01F02067 ○ ○ ○ ○ ● ○
GTW465	3	WW01F01906 ○ ○ ○ ○ ● ○
GTW490	0	WW01F02067 ○ ○ ○ ○ ○ ○
GTW491	0	WW01F02067 ○ ○ ○ ○ ○ ○
GTW495	1	WW01F01906 ○ ○ ○ ○ ○ ○
GTW550	7	WW01F02067 ○ ○ ○ ○ ● ○
GTW580	6	WW01F02073 ○ ○ ○ ○ ● ○
GTW680	0	WW01F02073 N/A
GTW681	0	WW01F02073 N/A
GTW685	1	WW01F02073 N/A
GTW690	10	WW01F02088 N/A



Wire Color Key	
XX-YY	XX:Wire color
YY-Wire gauge	
W:White	C:Brown
B:Black	R:Red
S:Grey	P:Pink
N:Blue	V:Purple
Y:Yellow	O:Orange
G:Green	T:Tan
GY:Green with Yellow	

Pressure Sensor

MODELS 200-491 ONLY	MODELS 680 ONLY
Inches of Water	Voltage
Empty	0.4
1"	0.7
2"	1.0
3"	1.4
4"	1.6
5"	1.8
6"	2.0
7"	2.2
8"	2.4
9"	2.6
10"	2.8
11"	3.0
12"	3.2

*To measure output voltage, connect the probes between pin 4 and pin 3. Shorting pin 3 to pin 2 will cause the main board to shut down.

Thermistor Resistance Table	
Temp(C)	Temp(F)
10	50
15	59
20	68
28	82.4
32	90
38	100
44	111
50	122
54	130
66	150
76	169

Tub Water Level Pressure Sensor

MODELS 200-491 ONLY	MODELS 680 ONLY
Inches of Water	Voltage
Empty	0.4
1"	0.7
2"	1.0
3"	1.4
4"	1.6
5"	1.8
6"	2.0
7"	2.2
8"	2.4
9"	2.6
10"	2.8
11"	3.0
12"	3.2


Resistance Table

Component	Resistance (Ω)
Drain pump	13.2
Lid Lock	70
Mode Shifter	5700
Motor (1/2HP)	3.1
Recirculation pump	31.7
Water Valves (Cold,Fab_Soft)	1374
Water Valves (Hot, Rinse)	1515


*These values are read from the leads while disconnected from the control PCB

**The values are approximate

***Measure lid lock resistance between pins 2 and 3 and pins 1 and 3 while lid is closed



*Replace UI harness first. If issue is still present, replace the whole assembly



Rotary Switch Resistance Table

Position	Resistance (kΩ)	Voltage
1	0.8	0.7
2	1.9	1.5
3	3.7	2.2
4	6.7	2.9
5	13.5	3.7
6	40.5	4.5

MODELS 220 & 210 ONLY

MODELS 410-450 ONLY

