




## PALM SPRINGS GAME CHAIR

Model #4185-800 Wood Game Chair

Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly is required. Customer Service Phone Number: 502-562-0000



## STEP 5

Attach the Metal Plate (P) to the bottom of the Chair Frame (M) with 4 Allen Bolts (D), 4 Spring Washers (E) & 4 Flat Washers (F) to secure in place.

## STEP 6

Finally attach each Caster (H) to each leg bottom and tighten using the Hex Wrench (K) that has been provided. Insert Wood Plugs (G) to cover bolt heads from Step 2. The assembly is now complete.