

*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

701703
MEDIA TOWER

ITEM:701703

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!











1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

50 MINUTES

PARTS IDENTIFICATION
















A	LEFT SIDE PANEL		1 PC	F	UPPER CROSS PANEL		2 PCS
B	RIGHT SIDE PANEL		1 PC	G	TOP PANEL		1 PC
C	BOTTOM PANEL		1 PC	H	BACK PANEL		2 PCS
D	ADJUSTABLE PANEL		1 PC	I	LEFT DOOR		1 PC
E	LOWER CROSS PANEL		1 PC	J	RIGHT DOOR		1 PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:701703

HARDWARE IDENTIFICATION**Z**

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 15g		1 PC	9	HANDLE SCREW φ3x15mm BLK		4 PCS
2	WOODEN DOWEL φ8x30mm		20 PCS	10	HINGE φ35mm SR		4 PCS
3	CAM BOLT φ7x35.5mm SR		12 PCS	11	HINGE SCREW φ4x15mm SR		16 PCS
4	CAM LOCK φ15x12mm SR		12 PCS	12	FOOT φ35xH19mm		4 PCS
5	BOLT φ9.5x55mm SR		8 PCS	13	FIXER		6 PCS
6	PIN FOR ADJUSTABLE SHELF φ4.9x8mm SR		4 PCS	14	FIXER SCREW φ3x19mm SR		6 PCS
7	DOOR CATCH		1 PC	15	STICKER φ20mm		2 PCS
8	HANDLE L=120mm BLK		2 PCS				

Z8,Z10,Z12 not included in blister packaging.

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 701703


STEP 1

COASTER
FINE FURNITURE

2
x 20

3
x 12




7
x 1




ITEM: 701703

COASTER
FINE FURNITURE

STEP 2




STEP 3



Apply glue on all wooden dowels to ensure integrity of the structure.


ITEM: **701703**

STEP 4



STEP 5



5
x 8





ITEM: **701703**

STEP 6

COASTER
FINE FURNITURE




STEP 7





ITEM: 701703

STEP 8


COASTER
FINE FURNITURE




STEP 9





HORIZONTAL BY
SCREW A ADJUSTMENT



LATERAL BY
SCREW B ADJUSTMENT






VERTICAL BY
SCREW C ADJUSTMENT





ITEM: **701703**

STEP 10


COASTER
FINE FURNITURE



STEP 11



ITEM: 701703



Note : Dimension tolerance $\pm 5\%$

ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture
may result in injury and damage.

1. To attach the anti-tip strap, securely mount one end to the top of the case piece with the 5/8" screw.
2. Position the case piece against the wall in the desired location.
3. Pull the anti-tip strap taut and mark the position of where you will secure the other end on the wall.
4. Drill a 1-1/4" hole in the spot you marked.
5. Tap in plastic wall plug.
6. Fasten anti-tip strap with wall screw provided.

(Please install the anti-tipping kit in the middle of the case piece if only have one set of anti-tipping kit.)

