Use & Care Guide

English

Models 405.2916#,405.2926#

Kenmore. Top Load Washer

= color number

Transform SR Brands Management LLC Hoffman Estates, IL 60192

www.kenmore.com



SAFETY INSTRUCTIONS	4
FEATURES	
Package contentsMain components	11
OPERATION REQUIREMENTS	13
Electrical requirementsWater requirements	13 14
Drainage requirements	
INSTALLATION INSTRUCTIONS	
Unpacking your washer	16
Tools you will need Connecting the water hoses	
Connecting the water hoses	
Level your washer	
Power on	24
Run a test cycle	25
WASHER USE	26
Control panel	
Washing a load of laundry	
Setting the control lock	
Washer options and settings	

WASHER CARE	35
Cleaning and Maintenance	35
BEFORE YOU CALL FOR SERVICE	
Troubleshooting tips	
Error codes	40

READ AND KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

This manual contains important information on the installation, use, and care of your appliance. Please read this manual carefully before installation and operation of this machine to prevent injury and property damage.

Warnings and Important Safety Instructions in this manual DO NOT cover all possible conditions and situations that may occur. It is your responsibility to use common sense, caution and care when installing, maintaining and operating your washer.



CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN



SAFETY INSTRUCTIONS

YOUR SAFETY AND THE SAFETY OF OTHERS ARE VERY IMPORTANT

To prevent injury to the user or other people and property damage, the instructions shown here must be followed. Incorrect operation due to ignoring of instructions may cause harm or damage, including death.

The level of risk is shown by the following indications.



This indicates that hazards or unsafe practices may cause serious personal injury or death.

To reduce the risk of fire, explosion, electric shock or personal injury when using your washing machine, you SHOULD follow these basic safety precautions.



This indicates that hazards or unsafe practices may cause minor personal injury or property damage.



This symbol indicates that there are important operating and maintenance instructions in the literature accompanying your washing machine.



WARNING

State of California Proposition 65 Warnings.

The California Safe Drinking Water and Toxic Enforcement Act requires the Governor of California to publish a list of substances known to the State of California to cause cancer, birth defects or other reproductive harm and requires businesses to warn of potential exposure to such substances. This product contains a chemical known to the State of California to cause cancer, birth defects or other reproductive harm. This appliance can cause low-level exposure to some of the substances listed, including benzene, formaldehyde and carbon monoxide. Cancer and Reproductive Harm - www.P65Warnings.ca.gov.



MARNING

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

IMPORTANT SAFETY INSTRUCTIONS

A WARNING

- Read all instructions before using the appliance.
- Use this appliance only for its intended purpose as described in this Owner's Manual
- Before use, the appliance must be properly installed as described in this manual.
- ALWAYS follow the fabric care instructions supplied by the garment manufacturer.
- Do not wash articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, other flammable or explosive substances as they give off vapors that could ignite or explode.
- Do not allow children to play on or in the appliance. Close supervision of children is necessary when the appliance is used near children.
- Before the appliance is removed from service or discarded, remove the lid of the washing compartment.
- Do not reach into the appliance if the tub is moving.
- Do not install or store this appliance where it will be exposed to the weather or freezing temperatures.
- Do not tamper with the controls.
- Do not repair or replace any part of the appliance or attempt any servicing unless it is specifically recommended in the user maintenance instructions or in published user repair instructions that you understand.
- Hydrogen gas is explosive. If the hot water system has not been used for two weeks or more, before using a washer, turn on all hot water faucets and let the water flow from each for several minutes. This will release any accumulated hydrogen gas. The gas is flammable, so do not smoke or use an open flame during this time.
- Keep the area underneath and around your appliance free of combustible materials (lint, paper, rags and so on), gasoline chemicals, and other flammable vapors and liquids.
- Do not place items exposed to cooking oil in your washer. Items contaminated with cooking oil may contribute to a chemical reaction that could cause a load to catch fire.
- This washer is not designed for maritime use or for mobile installations such as in RVs aircraft and other mobile platforms.
- Turn off the water faucets and unplug the washer if the machine is to be left for an extended period of time, such as during vacations.
- Packaging material can be dangerous for children. There is a risk of suffocation! Keep all packaging away from children.
- Always check the inside ofthe washer for foreign objects before loading laundry. Keep the lid closed when not in use.

A WARNING

- Plug the power cord into an AC 120V/60Hz wall socket rated at 15 amps or higher. Use the socket for this washer only. Do not use an extension cord.
 - Sharing a wall socket with another appliance, using a power strip, or extending the power cord may result in electric shock or fire.
 - Do not use an electric transformer. It may result in electric shock or fire.
 - Make sure that the power voltage, frequency and current match the product's specifications. Failing to do so may result in electric shock or fire
- Remove all foreign substances such as dust or water from the power plug terminals and contact points using a dry cloth on a regular basis.
 - Unplug the power plug and clean it with a dry cloth.
 - Failing to do so may result in electric shock or fire.
- Plug the power plug into the wall socket in the right direction so that the cord runs towards the floor.
 - If you plug the power plug into the socket in the opposite direction, the electric wires within the cable may be damaged and this may result in electric shock or fire.
- Plug the power plug into the wall socket firmly. Do not use a damaged power plug or loose wall socket, because this may result in electric shock fire.
- Do not pull or excessively bend the power cord. Do not twist or tie the power cord.
- Do not hook the power cord over a metal object. Place a heavy object on the power cord, insert power cord between objects, or push the power cord into the space behind the appliance, because this may result in electric shock or fire.
- Do not pull the power cord when unplugging the power plug.
 - Unplug the power plug by holding the plug.
 - Failing to do so may result in electric shock or fire.
- If the power plug or power cord is damaged, contact your nearest service center.
- Do not install on carpet. Install the washer on a level and solid floor that can support its weight. Failure to do so may result in abnormal vibration, noise or problems with the product.
- The washer is heavy. Two or more people may be needed to install and move the appliance. Failure to do so may result in bodily or other injuries.
- Store and install the washer where it will not be exposed to temperatures below freezing or exposed to outdoor weather conditions.
 Failure to do so may result in serious leak damage.
- Position the appliance so that the power plug is easily accessible. Failure to do so may result in electric shock or fire due to an electrical short circuit.
- Failure to follow all of the safety warnings in this guide may result in property damage or injury to persons.



Use and Maintenance Warnings and Precautions

- If the appliance is flooded, cut the power immediately and contact your nearest service center.
- If the appliance emits a strange noise, a burning smell or smoke, unplug the power plug immediately or turn off the breaker and contact your nearest service center. Failure to do so may result in electric shock or fire.
- In the event of a gas leak (such as propane or LP gas) ventilate the area immediately. Do not turn any appliance or light on or off.
- Do not use a ventilating fan.
- A spark may result in an explosion or fire.
- Do not force the washer lid open while the washer is operating (high temperature washing, drying or spinning).
 - Water flowing out of the washer may cause burns or cause the floor to be slippery. This may result in injury.
 - Forcing the lid open can damage the product or cause injury.
- Make sure to remove the packaging (sponge, styrofoam) attached to the bottom of the washer before using it.
- Do not insert your hand or a metal object under the washer. This may result in injury.
- Do not attempt to operate this appliance if it is damaged, malfunctioning, partially disassembled or has missing or broken parts, including a damaged cord or plug. This may result in electric shock, fire or death.
- Do not touch the power plug with wet hands. This may result in electric shock.
- Do not turn the appliance off by unplugging the power plug while the washer is in operation. Plugging the power plug into the wall socket again may cause a spark and result in electric shock or fire.
- Keep all packaging material well out of the reach of children, as packaging materials can be dangerous to children. If a child places a bag over his or her head, he or she may suffocate.
- Do not let children or infirm persons use this washer unsupervised. Failure to do so may result in electric shock, burns or injury.
- Do not attempt to repair, disassemble or modify the appliance yourself.
 - Do not use any fuse (such as copper, steel wire etc.) other than the standard fuse.
 - If you need to repair or reinstall the appliance, contact your nearest service center.
 - Failure to do so may result in electric shock, fire, problems with the product or injury.
- If any foreign substance such as water enters the appliance in any area other than the tub, unplug the power plug and contact your nearest service center. Failure to do so may result in electric shock or fire.
- If the water supply hose comes loose from the faucet and floods the appliance, unplug the power plug. Failure to do so may result in electric shock or fire.

- Do not mix chlorine bleach with ammonia or acids such as vinegar. Incorrect usage can produce poisonous gas, resulting in serious injury.
- Do not reach into the washer while parts are moving. Before loading, unloading or adding items, press the Start Pause button and allow the tub to come to a complete stop before reaching inside. Failure to do so may result in electric shock injury or fire.
- Do not allow children to play on or in the washer. Close supervision of children is necessary when the washer is used near children. As children grow, teach them the proper, safe use of all appliances. Failure to do so may result in serious injury.
- Keep laundry products out of reach of children. Observe all warnings on product labels and follow them. Failure to do so may result in serious injury.
- Disconnect this appliance from the power supply before attempting any user maintenance. Pressing the Power button does not disconnect this appliance from the power supply. Failure to do so may result in electric shock, injury or fire.
- Do not clean the appliance by spraying water directly onto it.
- Do not use benzene, thinner or alcohol to clean the appliance. This may result in discoloration, deformation, damage, electric shock or fire.
- Unplug the power plug when the appliance is not being used for long periods of time or during a thunder/lightning storm. Failure to do so may result in electric shock or fire.
- Keep hands and foreign objects clear of the lid and latch area when closing the lid. Failure to do so may result in personal injury.
- If the washer is contaminated by a foreign substance such as detergent, dirt, or food waste, unplug the power plug and clean the washer with a damp, soft cloth. Failure to do so may result in discoloration, deformation, damage or rust.
- The clear portion of the lid can be broken by a strong impact. Take care when using the washer. If the clear portion is cracked or broken, it may result in injury.
- After a water supply failure or when reconnecting the water supply hose, open the faucet slowly.
- Open the faucet slowly after a long period of non-use. The air pressure in the water supply hose or the water pipe may result in damage to a part or in water leakage.
- If a drain error occurs during an operation, check if there is a draining problem. If the washer is used when it is flooded because of a draining problem, it may result in electric shock or fire due to an electrical short circuit. Do not insert your hand or a metal object under the washer. This may result in injury.
- Insert laundry into the washer completely so that the laundry does not get caught in the lid. If laundry gets caught in the lid, it may result in damage to the laundry or the washer, or result in water leakage.
- Make sure that the faucet is turned off when the washer is not being used.
- Make sure that the water supply hose connectors are properly tightened. Failure to do so may result in property damage or injury.
- Open the faucet and check if the water supply hose connector is firmly tightened and that there is no water leaking before using the product.
 If the water supply hose connectors are loose, it may result in water leakage.

- Do not stand on top of the appliance or place objects (such as laundry, lighted candles, lighted cigarettes, dishes, chemicals, metal objects, etc.) on the appliance. This may result in electric shock, fire, problems with the product, or injury.
- Do not operate the appliance with wet hands. This may result in electric shock.
- Do not spray volatile material such as insecticide onto the surface of the appliance. As well as being harmful to humans, it may also result in electric shock, fire or problems with the product.
- Do not place an object that generates an electromagnetic field near the washer. This may result in injury due to a malfunction.
- Since the water drained during a high temperature wash or drying cycle is hot, do not touch the water. This may result in burns or injury.
- Do not wash, spin or dry water-proof seats, mats or clothing.
- Do not wash thick, hard mats even if the washer mark is on the care label. This may result in injury or damage to the washer, walls, floor or clothing due to abnormal vibrations.
- Do not operate the washer when the detergent dispenser is removed. This may result in electric shock or injury due to water leakage.
- Do not insert your hand into the detergent dispenser after opening it. This may result in injury because your hand may be caught.
- Do not place any non-laundry objects, such as shoes, food waste or animals into the washer. This can cause abnormal vibrations that can damage the washer, and in the case of pets, cause severe injury or death.
- Do not press the buttons using sharp objects such as pins, knifes, or fingernails. This may result in electric shock or injury.
- Do not wash laundry contaminated by oils, creams or lotions usually found in skin-care shops or massage clinics. This may result in the rubber seal becoming deformed and water leakage.
- Make sure that the water inlet pipe is connected and the tap is opened before washing clothes.
- Do not leave metal objects (safety pins, hair pins, and so on) or bleach in the tub for long periods of time. This may cause the tub to rust.
 - If rust appears on the surface of the tub, apply a neutral cleansing agent to the surface and use a sponge to clean it. Never use a metal brush.
- Do not use hot water from water cooling/heating devices. This may result in problems with the washer.
- Do not use natural hand-washing soap in the washer. If it hardens and accumulates inside the washer, it may cause problems with the product, discoloration, rust or bad odors.
- If using a washing net with this machine (not provided), do not wash laundry items such as bedding in the washing net. Doing so may result in injury due to abnormal vibrations. Place only smaller items such as lace socks and lingerie in the washing net.
- Do not use hardened powdered detergent. If it accumulates inside the washer, it may result in water leakage.
- Do not wash throw rugs or doormats. Doing so may cause sand to accumulate inside the washer, resulting in mechanical problems. SAVE THESE INSTRUCTIONS.



Grounding/Earthing

- This appliance must be properly grounded.
- Do not ground the appliance to a gas pipe, plastic water pipe or telephone line.
 - Improper grounding may result in electric shock, fire, explosion or problems with the product.
 - Never plug the power cord into a socket that is not grounded correctly. Make sure that the socket you use is grounded in correctly. Make sure that the socket you use is grounded in accordance with local and national codes.



WARNING


Grounding/Earthing

- Do not install this appliance near a heater or inflammable material.
- Do not install this appliance in a humid, oily or dusty location, or in a location exposed to direct sunlight or water (rain drops).
- Do not install this appliance in a location where gas may leak. Failure to do so may result in electric shock or fire.
- If the washer is moved to a new location, have it checked and reinstalled by a qualified service technician. Failure to follow this warning may result in electric shock or fire.
- Do not pull power cord or drain outlet hose to move appliance to desired location place.

FEATURES

Package Contents


Make sure that the following items came with your washer




NOTE:

• Use the filters to replace the rubber washers in the water hoses (faucet sides).

Main Components





OPERATION REQUIREMENTS

Electrical requirements



To reduce the risk of fire, electric shock, or injury to persons, read the SAFETY INSTRUCTIONS before operating this appliance.

Use a 120 Volt, 60Hz, 15 amp or higher fuse or circuit breaker. We recommend an individual branch circuit that serves only your washer.



A WARNING

Never use an extension cord

Electrical grounding is required for your washer.

You must ground your washer. In the event of a malfunction or breakdown, grounding reduces the risk of electric shock by providing a path of least resistance for the electric current.

Your washer is equipped with a power cord with a three-pronaed grounding plug for use in a correctly installed and grounded outlet.

The outlet must be correctly installed and grounded in accordance with all local codes and ordinances.



A WARNING

- You are responsible for providing adequate electrical services for your washer.
- An incorrectly connected equipment-grounding conductor can increase the risk of electrical shock. Check with a qualified electrician or serviceperson if you are not sure whether your washer is arounded correctly.
- Do not modify the power cord plug that came with your washer. If the plug does not fit the outlet, have the correct type outlet installed by a qualified electrician.
- To prevent unnecessary risk of fire, electrical shock or personal injury, all wiring and grounding must be done in accordance with the National Electrical Code ANSI/FNPA, No.70 Latest Revision and local codes and ordinances.
- Never connect the ground wire to plastic plumbing lines, gas lines or hot water pipes.
- Failure to closely follow these instructions may result in an abnormal vibrating and out-of-balance condition that could result in physical injury, property damage, and/or appliance damage.

To fill your washer in the correct amount of time, the water pressure needs to be between 14 and 116 psi (100 to 800 kPa).

If the water pressure is less than 14 psi (100 kPa):

- The water valve may fail or may not shut off completely.
- The time it takes to fill your washer may be longer than the time your washer controls allow. Your washer will turn off and report an error. A time-limit is built into the controls to prevent flooding in your home if a hose becomes loose.
- Water inlet hoses must be purchased separately. You can buy inlet hoses in various lengths up to 8 ft. (240 cm).

To avoid the possibility of water damage:

- Make sure that the water faucets are easily accessible.
- Turn off the faucets when you are not using your washer.
- Periodically check to make sure that water is not leaking from the water hose fittings.

Drainage requirements

Water requirements

The recommended height for the drain standpipe is 48 in. (122 cm).

The drain hose must be routed through the drain hose clip to the standpipe.

The stand pipe must be large enough to accept the outside diameter of the drain hose.


INSTALLATION INSTRUCTIONS


Unpacking your washer

A WARNING

- Packing materials can be dangerous to children. Keep all packing materials (plastic bags, polystyrene, and so on) well out of the reach of children.
- Do not operate your washer on the foam base cushion. Doing so will result in serious vibration, which could cause equipment damage or result in physical injury.
- Certain internal parts are intentionally not grounded and may present a risk of electric shock only during servicing.
 Service Personnel - Do not contact the following parts while the appliance is energized: Electrical Valve, Drain Pump and Main Motor and Retractor.

Remove the packing box and lift the washer up and away from the foam base cushion. Open the lid of the washer to take out all accessories including the protective foam.





Choosing a location



WARNING


- Do not install your washer in areas where water may freeze, because your washer always retains some water in its water valve, pump and hose areas. Frozen water can damage the valve, pump, hoses and other components.
- Never install on a platform or weakly supported structure.


For best performance, you must install your washer on a solid, level floor.


Wooden floors may need to be reinforced to minimize vibration or unbalanced load situations.

Carpeting and soft tile surfaces can contribute to excessive vibration, which can cause your washer to move slightly during the spin cycle.

Washer dimensions and installation measurements







* Required spacing

Installing in an alcove or closet

Minimum clearances between your washer and adjacent walls or other surfaces are:

• **Either side:** 1 in. (2.5 cm)


• Rear: 6 in. (15.2 cm)


• Closet Front: 2 in. (5.1 cm)

• **Top:** 24 in. (61 cm)

• Gap between the end of water valve and the wall: 6 in. (15.2 cm)

If you install your washer and dryer side-by-side in a closet, the closet front must have an unobstructed air opening of at least 72 square inches (465 square cm).





- A. Recessed area
- B. Side view closet or confined area

WARNING

- Appliance is located on a hard, level surface without carpeting or soft flooring that can obstruct ventilation.
- Is away from direct sunlight.
- Has adequate ventilation.
- Is not exposed to freezing temperatures (32 F or 0 °C).
- Is away from heat sources such as oil or gas.
- Has enough space so that the washer does not rest on its power cord.

Tools you will need



Pliers



Level



Adjustable wrench that opens to 1" (25 mm)


Connecting the water hoses

NOTE: The water supply hoses are not supplied with your washer and must be purchased separately.




A Caution

- Use new water supply hoses. Using old hoses can result in leakage. or overflow that can damage your property.
- Do not connect multiple water supply hoses together to increase the length of the hose. Hoses connected this way can leak and cause electrical shock. If a hose is too short, replace the hose with a longer, high-pressure hose.
- 1. Make sure that there are rubber gaskets inside the fittings at both ends of each new water hose. Remove the rubber washers in the faucet side of the hoses and replace them with the filters included in the packaged materials with your washing machine, Installing the water supply hoses without rubber washers can cause water leakage.




2. Tighten the hose and faucet fittings by hand until they are snug, then tighten them an additional two-thirds of a turn with pliers or a wrench. Pull the water supply hoses downwards to make sure that they are connected securely.




A Caution

Do not overtighten the fittings or apply tape or sealant to the faucets or water supply intake. This can damage the fittings.


3. Place the unconnected ends of the hoses into a bucket and turn on the faucets connected to the water supply hoses for 10 or 15 seconds to remove any foreign substances. Turn off the faucets.



4. Connect the ends of the water supply hoses to the water supply intake connections at the top of the washer. Make sure that the rubber washers are in place. The water supply hose connected to the hot faucet must be connected to the hot water supply intake and the water hose connected to the cold faucet must be connected to the cold water supply intake.



5. Tighten the fittings by hand until they are snug, and then tighten them an additional two-thirds of a turn with a pliers.



A Caution


- Do not overtighten the fittings or apply tape or sealant to the faucets or water supply intakes. This can damage the fittings.
- Make sure that the water supply hoses are not twisted or bent. A bent or twisted hose can leak and cause an electric shock due to the water leakage. To ensure the correct water usage, connect both hot and cold water faucets. If either or both are not connected, an error code could occur.
- 6. Turn on the hot and cold water supplies and check all the water supply intake connections and the faucets for water leaks.

Connecting the drain hose


A Caution

Make sure that the connection between the drain hose and the wash basin, standpipe or laundry tub is not airtight.


• Over the edge of wash basin - Secure the guide to the side of the basin wall with a hook, tape it or tie it with a piece of cord to prevent the drain hose from moving.



In a standpipe - The standpipe must be no shorter than 39 in. (99 cm) and no longer than 96 in. (244 cm).



• In a laundry tub - The laundry tub must be no shorter than 39-in. (99 cm) and no higher than 96-in (244 cm) maximum.



Level your washer



Caution


Do not use your washing machine without leveling. If your washer is not level, it may:

- Vibrate excessively which can cause your washer to malfunction.
- Make excessive noise.
- Indicate error codes when the washer is running.


Extend the leveling feet only as much as is necessary. If the feet are extended too much, your washer may vibrate.

Determine if the washer is level by checking the position of the tub or by using a level.

- 1. Slide the washer into position.
- 2. Open the lid of the washer, then pour water into the tub to the leveling circle. If the washer is level, the water will touch the leveling circle all the way around. If the washer is not level, the water will only touch part of the leveling circle.



3. If your washer is not level, carefully tilt your washer just enough to adjust the leveling feet on the bottom of your washer. Extend the feet only as much as is necessary. If the feet are extended too much, your washer may vibrate.



Power on

Plug the power cord into a well-grounded, 3-prong, 120 Volt 60 Hz approved electrical outlet, protected by a 15-amp or higher fuse or comparable circuit breaker. Your washer is grounded through the third prong of the power cord.

Run a test cycle

Run a test cycle to make sure that your washer is properly installed.

- 1. Load about 6 pounds (2.7 kg) of laundry into the tub.
- 2. Select the Cycles knob to turn on your washer.
- 3. Turn the cycle selector to select the Rinse & Spin cycle.
- 4. Press the Start Pause button to start the test cycle. Your washer should not rock or vibrate excessively when water fills the tub or when washing or spinning. The washer should drain well during the spin cycle.




A Caution

- If you detect any water leaks while the washer is filling or draining, check the water connections. See Connecting the water hoses on page 19 or Connecting the drain hose on page 22.
- If the washer rocks and/or vibrates excessively, level it again. See Level your washeron page 23.

WASHER USE

Control panel



1 Power

Press to turn on your washer. Press again to turn off your washer. If you leave your washer on and do not press the (b) button within 10 minutes, your washer will automatically turns off.

2 Start Pause

Press once to start the wash cycle. Press again to pause the cycle. If you pause the cycle, you can add or remove items, but you cannot change any settings. Press again to restart the cycle.

3 Cycle selector

Turn to select a wash cycle. The cycle you select determines the wash pattern for the cycle. For more information, see **Washer options and settings** on page 34.

4 Digital Display

The initial display is the total time for the cycle you select.

While your washer is running, the display shows the cycle process and time remaining in the cycle.

NOTE: the time shown is an estimate based on normal operating conditions. External factors (such as the load size, room temperature, incoming water temperature, and water pressure) can affect actual time.

If you set a delay time for the start of the cycle, the display shows the time when the cycle will start.

5 Wash Temp

Press to select the washing water temperature. The rinse water temperature is always cold.

6 Soil Level

Press to select the soil level. Different soil levels result in different washing times and wash cycle settings. For more information, see **Washer options and settings** on page 34.

7 Deep Fill

Select the Deep Fill feature for loads where extra water is desired. The Deep Fill feature is recommended for special case loads only, not for typical use. This feature will provide the deepest fill level possible; this will increase cycle time due to the additional time it takes to fill the washer.

8 Control Lock

Press and hold the Deep Fill button for 3 seconds to turn on the control lock function. Press and hold the button again for 3 seconds to turn off the function. When the control lock function is turned on, the only button that works is the (1) button and the **Deep Fill** button you use to turn off.

9 Water Level

Press to select the water level. Different water levels result in different washing times and wash cycle settings. For more information, see Washer opinions and settings on page 34.

[10] Fabric Softener

Add liquid fabric softener to the fabric softener compartment, and then press this button. The fabric softener will be added to the cycle at the correct time.

11 Accela Wash

Press to reduce the cycle running time. Selecting the function will use stronger wash rhythm to meet the same wash performance with shorter time.

12 Extra Rinse

Press to add an extra rinse to the wash cycle. Press again to cancel.

[13] Delay Start

Press to select a time when you want the cycle to begin. You can set the time up to 24 hours in advance in one-hour increments. The display shows the time when the cycle will start. For more information, see Set a delayed start time on page 31.

14 My Cycle

Press and hold for 3 seconds to remember your favorite washing cycle. Press once to load your favorite cycle settings.

15 Chime

Press and hold the **Accela Wash** button for 3 seconds to turn off the sound of button and cycle end.

Washing a load of laundry



WARNING

To reduce the risk of fire, electric shock, or injury to persons, read the SAFETY INSTRUCTIONS before operating this appliance.

Selecting a detergent

1. Turn on your washer

Press the () button to turn on your washer. Your washer's initial settings are:

- Normal | Casual on cycle selector with -- displayed on the digital display.
- Medium for the Soil Level.
- Warm for the Wash Temp.
- Water Level for the Auto.
- 2. Load your washer



🔼 Caution


Before loading your laundry, make sure that you remove coins, keys, and other hard objects and close zippers. These items may damage clothes.


- Sort laundry by fabric type, soil level, color, and load size.
- Fill the tub with dry, unfolded clothes. Load the tub no more than 3/4 full.


NOTE:

- Overloading may reduce washing efficiency, cause excess wear, and possibly cause creasing or wrinkling of the load.
- Wash delicate items such as bras, hosiery and other lingerie on the Delicates cycle with similar lightweight items. Delicate items recommend to use garment bag to wash.
- When washing big, bulky items (such as rugs or pillows) or a few smaller items (such as stuffed toys or one or two sweaters) that do not fill the tub completely, add a few towels to improve spin performance.
- Always use the **Bulky | Bedding** cycle for bedding items.
- When washing heavily soiled loads, do not overload your washer to ensure good cleaning results.

2. Add detergent and additives to the compartment








Loading the liquid or powder detergent compartment

- Pour the recommended amount of laundry detergent directly into the compartment before starting your washer.
- If you are using color-safe bleach, add it with the detergent to the detergent compartment.
- Do not use single use detergent packs in the detergent compartment with this washer. They should be placed in the tub before loading laundry.
- When using powdered detergent, remove the Liquid detergent compartment (A) from the detergent drawer. The washer will not dispense powered detergent from the liquid detergent compartment.



NOTE:

- When adding color-safe bleach with detergent, both laundry products should be in the same form (liquid).
- If the washer doesn't have a detergent compartment, add the detergent to the tub.

Loading the bleach compartment (liquid bleach only)

- Add chlorine bleach to the bleach compartment. Do not over-fill the compartment.
- There is no water inlet to the bleach dispenser, so the bleach will directly enter the tub when you pour it in.

A

Caution

- Avoid splashing or over-filling the compartment.
- Never pour undiluted liquid chlorine bleach directly onto the load or into the tub. Doing so can damage fabrics, by weakening of the fibers or stripping the color.

NOTE: Do not pour color-safe bleach into the bleach compartment. Instead, add it to the detergent compartment.

Loading the fabric softener compartment

Pour the recommended amount of liquid fabric softener into the softener compartment. The dispenser automatically releases liquid fabric softener at the correct time during the rinse cycle.




Caution

- Use the softener compartment ONLY for liquid fabric softeners.
- Do not use the **Downy Ball®** or similar products in the fabric softener compartment.
- Do not use liquid fabric softener that is too sticky as it may not mix with the water sufficiently.
- Be sure to select the Fabric Softener option when using fabric softener so that it is released in the rinse portion of the cycle.

3. Select the appropriate cycle and options for the load

Turn the cycle selector to select a washing cycle. For information on wash cycles, see Washer options and settings on page 34.



Optional: Use the control panel buttons (like Fabric Softener) to customize the washing cycle. For descriptions of buttons, see **Control** panel on page 26. For information about which buttons are available for each cycle type, see Washer options and settings on page 34.

4. (Optional) Set a delayed start time

You can program a wash cycle, then set a time when you want a wash cycle to begin.

Press the **Delay Start** button to turn on the delay start time function.



- Press the Delay Start button repeatedly to select the delay time you want. The delay start time, in hours, will be shown on the display, in sequence, from **0** to **24**, then back to **0**. You can also press and hold the **Delay Start** button to quickly adjust the time until the desired time appears on the display.
- If you want to change the wash cycle settings while you are setting the delay start time, turn the cycle selector. To return to setting the delay start time function, repeat Steps 1 and 2.

NOTE:

- Once the number of delay hours is reached by pushing the Delay Start button, release the button for three seconds and it will be set. The delay light will remain on.
- After the delay time is set, if you wish to change the delay setting, press the **Delay Start** button again until the desired hour is reached. Release the button for three seconds and it will be set.
- If you decide to cancel the delay setting, you can either turn the cycle selector or push the **Delay Start** button until **0** is reached.
- Ideally, you should set your cycle before setting the Delay, because turning the cycle selector after the delay is set cancels the delay.
- The Delay Start Time cannot be changed after the program has started.
- To cancel the delay start time function before you save the setting, press the **Delay Start** button until **O** appears on the display, or turn the cycle selector knob.

IMPORTANT:

- You can change settings or cancel the delay start time function anytime before you press the button by turning the cycle selector. The delay start time cannot be changed after you press the button.
- If you pressed the button, you can cancel the delay start time function by pressing the (1) button to turn off your washer, then pressing the (1) button again to turn it back on.

5. Start your washer

Press the button.

NOTE:

- If you have not set a delayed start time or if the delay time has expired, your washer starts the cycle and the Wash light turns on.
- As your washer moves from stage to stage in the wash cycle, the related light turns on (such as Rinse or Spin).
- If you set a delayed start time, the Delay Start light turns on and your washer starts counting down the start time.



If you need to pause the cycle (for example to add or remove items or adjust the load), press the | button, then open the lid. Your washer stops. When you are ready to resume washing, close the lid, then press the | button.

6. Unload your laundry

When the wash cycle is complete:

- The Screen shows End.
- Your washer beeps six times after the cycle is done.
- Your washer unlocks the lid.



• Open the lid and remove the laundry.

Setting the Control Lock

Your washer has a Control Lock function to prevent children from playing with your washer. When you turn on the Control Lock, the only buttons that work are the (¹) button and the **Deep Fill** button you use to turn off the Control Lock.

 Press and hold both the **Deep Fill** button for three seconds. The Control Lock light turns on.



 To turn off the Control Lock, press and hold both the Deep Fill button for three seconds.

NOTE:

• If you turn on the Control Lock function while the washer lid is open, E3 appears on the display. If you do not close the lid within 20 seconds, your washer sounds an alarm, displays CL, and drains all the water in the tub. To clear the alarm, press the (1) button to turn off your washer.

Washer options and settings

- Maximum load weight^{18.65} lbs (8.46 kg) (Dry clothes)
- **Bolded options are initial settings.** (dots) indicate options functions you can select.

		_			_					
Cycle	Fabric type	Display Time(min)	Soil level	Wash Temp	Water level	Delay Start	Extra rinse	Fabric softener	Deep Fill	Accela Wash
Normal Casual	Cotton, linen Towels, Shirts Sheets, Jeans Mixed loads	41	Extra Heavy Heavy Normal Light	Hot Warm Cool Cold	High Medium Low Auto	•	•	•	To Heavy Duty	•
Bulky Bedding	Large items like blankets and comforters	70	Extra Heavy Heavy Normal Light	Hot Warm Cool Cold	High Medium Low Auto	•	•	•	•	•
Heavy Duty	Heavily soiled cotton fabrics	50	Extra Heavy Heavy Normal Light	Hot Warm Cool Cold	High Medium Low Auto	•	•	•	•	•
Towels	Towels	43	Heavy Normal Light	Hot Warm Cool Cold	High Medium Low Auto	•	•	•	•	•
Whites	White Fabric	45	Extra Heavy Heavy Normal Light	Hot Warm Cool Cold	High Medium Low Auto	•	•	•	•	•
Express	Lightly soiled and small loads	27	Normal Light	Hot Warm Cool Cold	Medium Low Auto	•		•	•	
Delicates	Dress shirts Blouses Nylons Sheer/lacy	45	Heavy Normal Light	Hot Warm Cool Cold	Medium Low	•	•	•		•
Cold Clean	Cotton, linen Towels, Shirts Sheets, Jeans Mixed loads	51	Extra Heavy Heavy Normal Light	Cold	High Medium Low Auto	•	•	•	•	•
Rinse & Spin		20		Cold	High Medium Low Auto	•		•		
Clean Washer		70	Extra Heavy	Hot	High					

Note:

• Deep Fill option is not available for Normal cycle default settings. It automatically changes to the Heavy Duty cycle if you choose Deep Fill option under the setting(Normal cycle-Normal Soil level-without opinion selected). It is designed for higher cleaning performance.

WASHER CARE



Caution

Turn off the water faucets after final use. This shuts off the water supply to your washer and prevents the possibility of damage from escaping water. Leave the lid open to let the inside of your washer dry out.



WARNING

Certain internal parts are intentionally not grounded and may present a risk of electric shock only during servicing. Service Personnel - Do not contact the following parts while the appliance is energized: Electrical Valve, Drain Pump and Main Motor and Retractor.

CLEANING AND MAINTENANCE

Cleaning the exterior

Use a soft cloth to wipe up all detergent, bleach, or other spills as they occur.

Cleaning the interior

- Clean the interior of your washer periodically to remove any dirt, soil, odor, mold, mildew, or bacterial residue that may remain in your washer as a result of washing clothes.
- Failure to follow these instructions may result in unpleasant conditions, including odors or permanent stains in your washer or on your laundry.
- To remove hard water deposits, use a cleaner labeled "Washer safe".

Cleaning the control panel

- Clean with a soft, damp cloth. Do not use abrasive powders or cleaning pads.
- Do not spray cleaners directly on the panel. The control panel finish may be damaged by some laundry pre-treatment soil and stain remover products. Apply such products away from your washer and wipe up any spills or over-spray immediately.

Cleaning the detergent, bleach, or softener compartment

- Clean with a soft, damp cloth. Do not use abrasive powders or cleaning pads.
- Do not spray cleaners directly on the panel. The control panel finish may be damaged by some laundry pre-treatment soil and stain remover products. Apply such products away from your washer and wipe up any spills or over-spray immediately.

Cleaning the tub

The Clean Washer cycle is a self-cleaning cycle that removes the causes of odors that may occur inside your washer without using a cleaning agent. We suggest cleaning the tub about once a month.



Caution

Never use the Clean Washer cycle when laundry is in your washer. This may damage the laundry or your washer.

- With the tub empty, add one cup of chlorine bleach to the bleach dispenser.
- Press the Power button to turn on the washer.
- Turn the cycle selector to Clean Washer.
- Press the button.

Storing your washer

You can damage your washer if you do not remove water from hoses and internal components before storage.

To prepare your washer for storage:

- Select the Express cycle and add bleach to the washer. Run your washer through the cycle without a load.
- Turn the water faucets off and disconnect the inlet hoses.
- Unplug your washer from the electrical outlet and leave your washer lid open to let air circulate inside the tub.



Caution

If your washer has been stored in below-freezing temperatures, allow time for any leftover water in your washer to dry out before storing.

BEFORE YOU CALL FOR SERVICE...

Troubleshooting Tips

Save time and money! Review the charts on the following pages first and you may not need to call for service.

Problem	Solutions
Washer does not start	 Make sure that your washer is plugged in. Make sure that the lid is closed. Make sure that the water source faucets are open. Make sure that you press the button to start your washer. Before your washer starts to fill, it makes a series of clicking noises to make sure that the lid is locked and to do a quick drain. Make sure that the Control Lock is not activated. See Setting the Control Lock on page 33. Make sure that the Delay Start option is not turned on. See (Optional) Set a delayed start time on page 31. Check the fuse or reset the circuit breaker.
No water or not enough water	 Make sure that both faucets are fully turned on. Make sure that the water pressure is in the range listed in Water requirements on page 14. Make sure that the water inlet hoses are not kinked. Straighten if necessary. Disconnect the hoses and clean the screens. The hose filter screens may be clogged.
When washer has excessive vibration or noise	 Make sure that your washer is set on a level surface. If the surface is not level, adjust your washer's feet to level your washer. Make sure that your washer is not touching any other object. Make sure that the laundry load is balanced. During the spin process, if clothes are piled to one side of the tub, your washer may stop because of the imbalance. Your washer tries up to three times to solve the probler automatically. If the washer cannot solve the problem, try to manually redistribute clothes inside the tub.

Problem

Solutions

Washer stops • Make sure that the power outlet is a working outlet. • Check the fuse or reset the circuit breaker. • Close the lid, then press the button to start your washer. For your safety, your washer does not spin unless the lid is closed. • Before your washer starts to fill, it makes a series of clicking noises to make sure that the lid is locked and to do a quick drain. • Sometimes your washer may pause between stages in the cycle. Wait to see if your washer starts again. • Disconnect the inlet hoses and clean the screens periodically. The hose filter screens may be cloqued. Lid is locked • Press the button to pause the washer. You cannot open the lid if the washer is running. or will not open • After you pause the washer, it may take a few seconds for the lid lock to release. • If the lid is locked when your washer is not running, press the (1) button to turn on your washer. • If power fails while your washer is running, when power is restored, the lid unlocks. Your washer waits three minutes then runs the rest of the cycle. Washer does • Check the fuse or reset the circuit breaker. not drain or • Close the lid, then press the **\|** button to niga start your washer. For your safety, your washer does not spin unless the lid is closed. Make sure that the drain hose is not kinked. Straighten as necessary. • Make sure that the height of the drain hose is within specified limits. See Drainage requirements on page 14. • The pipes to your sewer system may be clogged. Contact a plumber or qualified repair professional. The water Make sure that you have selected the correct temp. temperature Make sure that the water source faucets are fully is not correct opened. Make sure that the hoses are connected to the correct faucet and water intake connections on your washer, then flush the lines. See Connecting the water hoses on page 19. • Disconnect the hoses and clean the screens. The hose filter screens may be clogged.

Problem	Solutions
Load is too wet at the end of the cycle	 Use a high-efficiency detergent to reduce oversudsing. See Selecting a detergent on page 29. The load may be too small. Very small loads (one or two items) may become unbalanced and not spin out completely.
Water leaks	 Make sure that all hose connections are tight. See Connecting the water hoses on page 19 and Connecting the drain hose on page 22. Make sure that the end of the drain hose is correctly inserted and secured to the drainage system. Make sure leak is not from drainage system. See Connecting the drain hose on page 22. Avoid overloading. Use a high-efficiency detergent to reduce oversudsing. See Selecting a detergent on page 29.
Oversuds condition	 Use a high-efficiency detergent to reduce oversudsing. See Selecting a detergent on page 29. If you have "soft" water, reduce the amount of detergent. For small or lightly soiled loads, reduce the amount of detergent.
Prevent odor	 Periodically run a Tub Clean cycle to clean the tub. See Cleaning the tub on page 35. Use a high-efficiency detergent to reduce oversudsing. Excessive suds collect in nooks and crannies and cause odor. See Selecting a detergent on page 29. Dry the interior of your washer after the total cycle has finished.

ERROR CODES

Description	Reason	Solutions
E1	The inlet water or water level change is insufficient or the target water level in not reached within the specified time.	 Make sure that the lid is not open. Make sure that water is not leaking. See No water or not enough water on page 37.
E2	The unit takes more than 10 minutes to drain.	• See Washer does not drain or spin on page 38.
E3	The lid is open.	Close the lid.Contact an authorized service technician.
E4	Your washer is out of balance more than three times in spin operation.	Relevel the load, if can not solve, Contact an authorized service technician.
E5	Your washer is not level. Impact switch failed.	 Adjust the washer level refer to installation. If the situation continues, contact an authorized service technician.
E7	The holl sensor failed.	Contact an authorized service technician.
F5	Load sensing failed.	Contact an authorized service technician.
F8	Water level sensor failed.	Contact an authorized service technician.
Fd	Lid lock failed.	Contact an authorized service technician.
C9	The PCB failed.	Contact an authorized service technician.
CL	The lid has been open for over 20 seconds with the Control Lock function activated.	 Press the Power button to turn off your washer. Turn off the Control Lock function see Setting the Control Lockon page 33. Contact an authorized service technician.

Kenmore Limited Warranty

Kenmore® products are sold and distributed by Kenmore and Kenmore authorized distributors and licensees in various countries.

For information on the limited warranty and authorized provider applicable to your product and country please visit: https://www.kenmore.com/warranty-information/

For a printed copy please contact us at 1-844-553-6667 or at the address below:

ATTN: Kenmore Warranty Request 5407 Trillium Suite B120 Hoffman Estates. IL 60192

Kenmore.

For Customer Care go to:
 www.kenmore.com/contact-us/
to select your local area or retailer where this appliance was
 purchased for contact information on scheduling
in-home repair service or ordering replacement parts.

Para el servicio de atención al cliente diríjase a:
www.kenmore.com/contact-us/
Aquí podrá seleccionar el área o el establecimiento local
donde compró el electrodoméstico para obtener
información de contacto y programar un servicio de
reparación a domicilio o solicitar piezas de repuesto.

Pour l'assistance à la clientèle, visitez:
www.kenmore.com/contact-us/
et sélectionnez votre région ou le détaillant auprès
duquel cet appareil a été acheté afin d'obtenir des
informations sur la programmation d'un service de
réparation à domicile ou la commande de pièces de
rechange.

