

---

# 30" SELF-CLEANING OVEN

## FIRST USE

---

|                                     |    |
|-------------------------------------|----|
| Get to know your appliance          | 3  |
| Set up the oven                     | 6  |
| Select a cooking method or function | 7  |
| Set the timer                       | 9  |
| Set Delayed cook or Auto Off        | 10 |
| Use the temperature sensor          | 11 |
| Use Multi shelf                     | 12 |
| Connect to Wi-Fi                    | 13 |
| Enable Remote mode                  | 14 |
| Turn Sabbath mode on                | 15 |
| Enable Voice to open                | 16 |
| Cooking methods and functions       | 17 |
| Clean and maintain your oven        | 18 |
| PREMIÈRE UTILISATION   FR           | 19 |
| PRIMER USO   SP                     | 39 |

**FISHER & PAYKEL**

**US CA**

## **30" SELF-CLEANING OVEN**

---

### **MINIMAL**

OB30SMPUB3, OB30SMPUG3,  
OB30SMPUNB3, OB30SMPUNG3

### **CONTEMPORARY**

OB30SCPUDX3, OB30SCPTDX3, OB30SCPTDB3

### **PROFESSIONAL**


OB30SPPUX3, OB30SPPTX3

# GET TO KNOW YOUR APPLIANCE




## How to get the best results from your oven

- Download the app to use remote mode and get updates.
- Set up and condition the oven before you use it.
- Run regular **CLEAN** cycles.
- Register your product to get streamlined service support.



# GET TO KNOW YOUR APPLIANCE




## HOME SCREEN

|                           |                                                                                                                                      |
|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------|
| <b>Control dial*</b>      | <ul style="list-style-type: none"><li>Turn the dial to scroll.</li><li>Press to select.</li><li>Press and hold to go back.</li></ul> |
| <b>Open Door button**</b> | Press and hold to open or close the oven door.                                                                                       |
| <b>Menu</b>               | Press to access additional features and settings.                                                                                    |
| <b>Cooking methods</b>    | Choose from a range of optimized cooking methods and traditional functions.                                                          |

\*Some models only

\*\*Handleless models only

# GET TO KNOW YOUR APPLIANCE



## MENU

|                                                                                     |                 |                                                                                                                                                                               |
|-------------------------------------------------------------------------------------|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | <b>LIGHT</b>    | Press <b>LIGHT</b> to turn the oven lights <b>ON/OFF</b> .                                                                                                                    |
|    | <b>TIMER</b>    | Set a timer to keep track of cooking times or as a general timer. The timer does not turn the oven off.                                                                       |
|    | <b>CLEAN</b>    | Set a self clean cycle to clean the inside of the oven. Refer to Care and Maintenance guide for full instructions.                                                            |
|   | <b>LOCK</b>     | Lock the controls to prevent accidental use. When locked, the controls will be unresponsive and the appliance will not turn on. Press and hold the screen anywhere to unlock. |
|  | <b>SETTINGS</b> | Adjust the settings to suit your preferences or set up a Wi-Fi connection.                                                                                                    |
|  | <b>REMOTE</b>   | Connect appliance to your mobile device to operate it remotely via the app.                                                                                                   |
|  | <b>BACK</b>     | Go back one level.                                                                                                                                                            |
|  | <b>EXIT</b>     | Press to return to the home screen.                                                                                                                                           |


## SET UP THE OVEN

We recommend conditioning your oven for 1 hour before initial use to eliminate any manufacturing residue. A small amount of smoke may be present. Ensure the kitchen is well ventilated.



### Remove cable ties

Remove any packaging and the cable ties that are securing the shelves and trays.



### Condition the oven

Select **BAKE**, then **SKIP**, and set the oven at 400°F for 30 minutes.

Select **OPTIONS**, **CHANGE FUNCTION**, and set to **AERO BROIL** for 5 minutes then **TRUE AERO** for 20 minutes.


Wipe clean once oven has cooled.

## SELECT A COOKING METHOD OR FUNCTION


Select a cooking method and follow onscreen instructions for an optimized cooking environment, or choose from a range of traditional cooking functions.



1. Position the shelves at the desired height.




2. Select a cooking method or scroll to select TRADITIONAL FUNCTIONS.



3. Select a food type or an oven function as required.

## SELECT A COOKING METHOD OR FUNCTION




**4.** Adjust the temperature if needed and add any additional timers or cooking options, then press **START**.

Press **STOP** at any point to exit cooking.



### Methods with preheat

A progress bar will show while the oven is heating. To prevent burning, place food in the oven once it reaches temperature.



### Methods without preheat


If there is no progress bar, place food in the oven when you start the cook.

Press **STOP** at any point to turn the oven off.


## SET THE TIMER




Use the timer to keep track of cooking times or as a general timer. The timer does not turn the oven off.



1. Select **TIMER** from the menu or from the cooking screen.



2. Scroll to set the desired duration, then press **CONFIRM** to start the countdown.




3. The remaining time will show on the screen. Press it to adjust or cancel the timer.

When the timer is complete, an alert will sound and a message will show on the screen. Press **DONE** to dismiss the message.


## SET DELAYED COOK OR AUTO OFF



You can set **DELAYED COOK** or **AUTO OFF** when using most cooking methods or functions. Use **DELAYED COOK** to set the oven to turn on later, cook for a set duration and turn off at a set time. Use **AUTO OFF** to set the oven to turn off after a set duration.



Press **OPTIONS** on the cooking screen, then select **DELAYED COOK** or **AUTO OFF**.




### Delayed cook

Set a cook duration and a cooking end time, and press **CONFIRM**.

Cover food or place it on a lower shelf in oven to prevent burning as the oven preheats.

Not recommended with **BROIL**, **AERO BROIL** or **AIR FRY**.



### Auto off

Set a cook duration, and press **CONFIRM**.


The oven will turn off after the set duration.

## USE THE TEMPERATURE SENSOR




Use the wired temperature sensor or a compatible wireless sensor to monitor your cook to achieve your desired doneness.

Insert the sensor into the thickest part of the protein, avoiding fat and bone, and ensure the tip doesn't protrude or touch cookware.




1. Select a cooking method and press **OPTIONS** or **TEMP SENSOR**.



2. Select the relevant protein and desired doneness or removal temperature, then press **START**.

Allow your oven to preheat if necessary.



3. Place food in the oven. If using the wired sensor, plug it into the socket on the inside-left of the oven until it clicks into place.

Rest meat before serving to allow the internal temperature to rise.


## USE MULTI SHELF




Use the **MULTI SHELF** option so heat distributes evenly when you cook food on more than one shelf at a time. You can turn it on or off before and during cooking.



1. Select a cooking method or function and press **MULTI SHELF**.



2. Press **ON**, then **CONFIRM**.




3. Press **START**, and allow your oven to preheat if necessary before putting the food in.  
Press **MULTI SHELF** again to turn it off.

## CONNECT TO WI-FI




Connect your appliance to your home wireless network to receive updates and connect to the app.

It may take up to 10 minutes to connect your appliance.




### On your mobile device

Scan the QR code to download the app, then create an account and add your appliance.



### On your appliance

1. Ensure your home Wi-Fi network is on, then go to **MENU** and select **SETTINGS**.




2. Select **WI-FI** and follow the onscreen instructions to connect.


## ENABLE REMOTE MODE




Enable **REMOTE MODE** to operate your appliance remotely via the app.



1. Go to **MENU**, and select **REMOTE**.



2. Select **ON**, then press **CONFIRM**.



### Disable Remote Mode

Go to **MENU**, and select **REMOTE**. Select **OFF**, then press **CONFIRM**.


## TURN SABBATH MODE ON

For the Sabbath observant. Sets your oven to heat continuously for as long as needed. The display will be unresponsive and no tones or alerts will sound. Your oven will stay in Sabbath mode until cancelled. See the Care and maintenance guide for manual door-opening instructions.

LOW  
Keep hot food warm

MODERATE  
Reheat cold food


HIGH  
Cook raw food



1. Go to **SETTINGS** and select **SABBATH MODE**.



2. Set a heat level and press **CONFIRM**. Follow the onscreen instructions to set the oven light on or off and to set a **SABBATH MODE** duration.




3. The oven will stay in **SABBATH MODE** until the set duration has passed or until cancelled.  
Press and hold the screen to cancel **SABBATH MODE**.


## ENABLE VOICE TO OPEN

Enable 'Voice to open' on handleless models to open the oven door. Your appliance must be connected to Wi-Fi and have Remote Mode enabled. Voice control also requires a smart speaker or your mobile device to control the oven door.

Only use voice control when you can see the oven and it is safe to open the door.



1. Go to **SETTINGS** and select **VOICE OPEN DOOR**.



2. Select **ON**, then **CONFIRM**.  
Follow the instructions on the screen and in the app to complete the setup.

## COOKING METHODS AND FUNCTIONS

Method-led cooking lets you select what you want to cook and how you want to cook it. Your oven will then recommend the optimal heat type and temperature for perfect cooking results. Explore the full range of methods and functions available.

|                        |              |              |
|------------------------|--------------|--------------|
| <b>Cooking methods</b> | Bake         | Slow Cook    |
|                        | Broil        | Reverse Sear |
|                        | Roast        | Dehydrate    |
|                        | Air Fry      | Proof        |
|                        | Warm         |              |
| <b>Functions</b>       | Air Fry      | Maxi Broil   |
|                        | Bake         | Classic Fan  |
|                        | Classic Bake | Rapid Proof  |
|                        | Dehydrate    | Roast        |
|                        | Aero Bake    | Slow Cook    |
|                        | True Aero    | Vent Bake    |
|                        | Aero Broil   | Warm         |
|                        | Broil        |              |

## CLEAN AND MAINTAIN YOUR OVEN

Make these steps a regular part of your cleaning routine to get the best results from your appliance.

### **Clean door glass after each use**

Wipe the door glass clean after each use and before running a pyrolytic self clean cycle to prevent stains becoming baked on.

### **Clean inside of the oven after each use**

Clean up any easy-to-reach spills, food or grease stains in the oven to prevent them becoming baked on.

### **Run regular pyrolytic self clean cycles**

Run a CLEAN cycle as required to remove food residue and buildup in the oven.



### **Care, maintenance and troubleshooting information**

Scan the QR code or visit [fisherpaykel.com](http://fisherpaykel.com) and search for your model code.

OB30SMPUB3, OB30SMPUG3, OB30SMPUNB3, OB30SMPUNG3,  
OB30SCPUDX3, OB30SPPUX3, OB30SCPTDX3, OB30SCPTDB3 OB30SPPTX3

