

# ASSEMBLY INSTRUCTIONS

MODEL #

### CM3020SC-2PK

#### **Questions?**

GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)

#### **TOOLS REQUIRED**




Allen Wrench




2 - People Recommended

#### ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.








Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



# PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.


















#### Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

#### **Suitable Location**

Assembling near the area of the intended location is highly recommended.

#### **Sufficient Space**

Make sure you have enough space to move around during the assembly.

#### **Avoid Scratches**

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.


#### **Flat Surface**

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

# ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Save the instructions and store any supplied tools for later maintenance.

After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



## Exploded View



## ASSEMBLY INSTRUCTIONS

