

*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

708224
MEDIA TOWER

ITEM:708224

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

60 MINUTES

PARTS IDENTIFICATION









NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:708224

HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	7	PLASTIC COVER Ø 52mm		1 PC
2	WOODEN DOWEL Ø8x30mm		36 PCS	8	HINGE Ø35mm SR		4 PCS
3	CAM BOLT Ø7x35.5mm SR		32 PCS	9	HINGE SCREW Ø4x15mm SR		16 PCS
4	CAM LOCK Ø15x12mm SR		32 PCS	10	FIXER		6 PCS
5	PLASTIC FEET Ø15mm		4 PCS	11	FIXER SCREW Ø 3x19mm SR		6 PCS
6	PIN FOR ADJUSTABLE SHELF Ø4.9x15mm SR		4 PCS	12	STICKER Ø20mm		6 PCS

Z7, Z8 not included in blister packaging.









NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: 708224

STEP 1


COASTER
FINE FURNITURE



Apply glue on all wooden dowels to ensure integrity of the structure.



INCORRECT
CORRECT





Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM: **708224**

STEP 2



COASTER
FINE FURNITURE





ITEM: **708224**

STEP 3

COASTER
FINE FURNITURE




STEP 4





ITEM: **708224**

STEP 5

COASTER
FINE FURNITURE





STEP 6








ITEM: **708224**

STEP 7




STEP 8





ITEM: **708224**

STEP 9

COASTER
FINE FURNITURE






STEP 10






ITEM: **708224**

COASTER
FINE FURNITURE

STEP 11






STEP 12




ITEM: **708224**

STEP 13

COASTER
FINE FURNITURE






STEP 14





ITEM: **708224**

STEP 15


COASTER
FINE FURNITURE




STEP 16





HORIZONTAL BY
SCREW A ADJUSTMENT



LATERAL BY
SCREW B ADJUSTMENT






VERTICAL BY
SCREW C ADJUSTMENT



ITEM: **708224**

STEP 17

COASTER
FINE FURNITURE






ITEM: **708224**


STEP 18

COMPLETE

COASTER
FINE FURNITURE



ITEM: 708224



Note : Dimension tolerance $\pm 5\%$

ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT


WARNING

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture may result in injury and damage.

This restraint must be screwed to a wood stud on the wall, using the long screw provided.


STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.



STEP 2

Locate the wood stud on the wall, and secure the other bracket, 2 inches below the back of the unit.



STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end, and drag it through, until the slack is removed. Ensure that the strap is securely laced and locked.

