



Furniture of America®

## Assembly Instructions

For more information contact our team: [service.ec@foagroup.com](mailto:service.ec@foagroup.com)

### AM7973T/F/Q



#### ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY  DIFFICULT


#### Tools Required For Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(Not Included)

Power Drill  
(Recommended)



(Not Included)




2 Person Recommended




## ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


### BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




**HARDWARE**

**A**




**Screw x6**

**B**




**Bolt x8**

**C**



**Bolt x8**


**D**




**Allen Wrench x1**




# PARTS



Box 1 HB/FB



Box 2 Rails x2




Wires x3  
Wires only come with Twin and Full

## STEP 1 Twin/Full/Queen




2. Secure bolts (#B) into side rails and HB/FB by using bolt (#C) from the outside view.

1. Align side rail to the holes of the HB/FB as indicated in the diagram. Insert the bolts (#B) to the holes of the side rails connecting to the HB/FB from the inside view.



Outside View



Inside View



## STEP 2 Twin/Full



Align 3 wires 12" from end and center on rails. Then, secure screws (#A) as shown in diagram.

