

SAMSUNG

User Manual



VA81-01146B-00
NSPB101270A-00

SWA-9200S

© 2022 Samsung Electronics Co., Ltd. All rights reserved.

Contact **SAMSUNG WORLD WIDE**

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care Center.

HEADQUARTERS

Samsung Electronics Canada Inc. 2050 Derry Road West, Mississauga, Ontario L5N 0B9 Canada

TEL: 1-800-SAMSUNG (1-800-726-7864)

www.samsung.com/ca/support

Country	Samsung Service Center ☎	Web Site
CANADA	1-800-SAMSUNG(726-7864) 1-844-SAM-PAYS (726-7297)	www.samsung.com/ca/support (English) www.samsung.com/ca_fr/support (French)
U.S.A	1-800-SAMSUNG (726-7864) 1-844-SAM-PAYS (726-7297)	www.samsung.com/us/support

SAFETY INFORMATION

Thank you for purchasing this product (SWA-9200S).

CAUTION
RISK OF ELECTRIC SHOCK. DO NOT OPEN.

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER (OR BACK). NO USER-SERVICEABLE PARTS ARE INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL. Refer to the table below for an explanation of symbols which may be on your Samsung product.

	This symbol indicates that high voltage is present inside. It is dangerous to make any kind of contact with any internal part of this product.
	This symbol indicates that this product has included important literature concerning operation and maintenance.
	Class II product : This symbol indicates that it does not require a safety connection to electrical earth (ground). If this symbol is not present on a product with a power cord, the product MUST have a reliable connection to protective earth (ground).
	AC voltage : This symbol indicates that the rated voltage marked with the symbol is AC voltage.
	DC voltage : This symbol indicates that the rated voltage marked with the symbol is DC voltage.
	Caution, Consult instructions for use : This symbol instructs the user to consult the user manual for further safety related information.

- The slots and openings in the cabinet bottom are provided for necessary ventilation. Do not block or restrict the reliable operation of this apparatus from overheating, these slots and do not be blocked or covered.
- Do not place this apparatus in a location where it is exposed to direct sunlight, such as a bookcase, or built-in cabinet where ventilation is provided.
- Do not place this apparatus near a heat register, or where it is exposed to sunlight.
- Do not place vessels (vases etc.) on this apparatus. A water spill on this apparatus may cause an electric shock.
- Do not expose this apparatus to rain, water (near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool etc.). If this apparatus accidentally gets wet, unplug it and contact an authorized service center.
- Do not overload wall outlets, extension cords, or power strips. Use only the adaptors beyond their capacity, since overloading may cause a fire or electric shock.
- Route power-supply cords so that they do not become frayed or damaged. Do not be walked on or pinched by items placed on top of the cords.
- Pay particular attention to the location of the power cord at wall outlets, and the point where the power cord enters the apparatus.
- To protect this apparatus from a lightning surge, unplug it from the wall outlet when it is left unattended and unused for a long time. This is especially important for the antenna or cable system. This will protect the apparatus from the power surge to the set due to lightning and power line surges.
- Before connecting the AC power cord to the set, make sure the voltage designates on the AC power cord matches the adaptor corresponds to the local electrical outlet. Never insert anything metallic into the AC power cord outlet, make sure the voltage designates on the adaptor matches the voltage of this apparatus. Doing so may create a fire or electric shock.
- To avoid electric shock, never touch the power cord or the power cord outlet. When unplugging the power cord, always pull on the power cord, not the plug. Do not pull on the power cord outlet, always pull on the power cord.
- Unplug by pulling on the power cord, not the plug. Do not pull on the power cord outlet, always pull on the power cord.
- If this apparatus does not operate properly, do not attempt to repair it. Contact an authorized dealer or service center.
- Maintenance of Cabinet.
- Before connecting other components, make sure to turn them off.

SAMSUNG

Manuel utilisateur



VA81-0T146B-00
NSPBI01270A-00

SWA-9200S

© 2022 Samsung Electronics Co., Ltd. Tous droits réservés.

Comment contacter Samsung dans le monde

Si vous avez des suggestions ou des questions concernant les produits Samsung, veuillez contacter le Service Consommateurs Samsung.

SiÈGE SOCIAL

Samsung Electronics Canada Inc. 2050 Derry Road West, Mississauga, Ontario L5N 0B9 Canada

TEL: 1-800-SAMSUNG (1-800-726-7864)

www.samsung.com/ca/support

Pays	Centre de service de Samsung ☎	Site Web
CANADA	1-800-SAMSUNG (726-7864)	www.samsung.com/ca/support (English)
	1-844-SAM-PAYS (726-7297)	www.samsung.com/ca_fr/support (French)
U.S.A	1-800-SAMSUNG (726-7864)	www.samsung.com/us/support
	1-844-SAM-PAYS (726-7297)	

INFORMATIONS RELATIVES À LA SÉCURITÉ

Nous vous remercions d'avoir fait

l'acquisition de ce produit (SWA-9200S).

MISE EN GARDE RISQUE DE CHOC ÉLECTRIQUE NE PAS OUVRIR	
	ATTENTION : POUR ÉVITER LES RISQUES DE CHOC ÉLECTRIQUE, NE DÉMONTÉZ PAS LE CAPOT. L'APPAREIL NE CONTIENT PAS DE PIÈCES RÉPARABLES PAR L'UTILISATEUR. S'ADRESSER À UN SERVICE APRÈS-VENTE QUALIFIÉ. Reportez-vous au tableau ci-dessous pour comprendre les symboles pouvant figurer sur votre produit Samsung.
	Ce symbole indique la présence d'une haute tension à l'intérieur. Tout contact avec une pièce interne de l'appareil présente un danger.
	Ce symbole vous informe qu'une documentation importante relative au fonctionnement et à l'entretien est fournie avec le produit.
	Produit de catégorie II : Ce symbole indique qu'il ne nécessite pas une connexion de sécurité à la terre (masse). Si ce symbole n'est pas présent sur un produit équipé d'un cordon d'alimentation, le produit DOIT être raccordé à la terre de manière fiable à des fins de protection.
	Tension CA : Ce symbole indique que la tension nominale est la tension CA.
	Tension CC : Ce symbole indique que la tension nominale est la tension CC.
	Attention, consultez les instructions aux fins d'utilisation : Ce symbole indique à l'utilisateur qu'il doit consulter le guide d'utilisation pour avoir de l'information au sujet de la sécurité.

- Les fentes et événements présents à l'arrière sont fournis à des fins de ventilation. Le bon fonctionnement de l'appareil et d' de surchauffe, ces fentes et ouvertures obstruées ni couvertes.
- L'appareil ne doit pas être placé dans un clos tel qu'une bibliothèque ou une sauf si une ventilation adéquate est d'un radiateur ou d'une grille d'air un endroit exposé à la lumière directe.
- Aucun récipient contenant de l'eau ne doit être placé sur l'appareil. L'eau peut être placée sur l'appareil.
- L'appareil ne doit pas être exposé à la proximité d'une source d'eau, par exemple un lavabo, un évier, un bac de lavage, une piscine, etc. Si l'appareil est mouillé, débranchez-le et appelez immédiatement un technicien agréé.
- Évitez de surcharger les prises murales les adaptateurs, car cela présente un risque d'électrocution.
- Disposez les cordons d'alimentation d'une manière sûre et sécurisée. Ne les laissez pas traîner sur le sol ou sous des tapis. Ne les laissez pas sous des meubles ou sous des vêtements.
- En cas d'orage, ou bien lorsque vous ne n'utilisez pas votre appareil pendant une période prolongée, débranchez celui-ci de la prise murale. Également, débranchez l'antenne ou le connecteur de l'appareil. Prenez des précautions d'urgence pour éviter que l'appareil ne soit endommagé par la foudre ou par des surtensions.
- Avant de raccorder le cordon d'alimentation de l'adaptateur CC, vérifiez que la tension du cordon correspond bien à la tension d'entrée de l'appareil.
- N'insérez jamais d'objet métallique dans la prise murale. N'insérez jamais d'objet métallique dans la prise murale.
- Pour éviter tout risque d'électrocution, ne touchez pas les doigts à l'intérieur de l'appareil. Seul le technicien qualifié est habilité à ouvrir cet appareil.
- Veillez à brancher le cordon d'alimentation de l'appareil dans la prise murale de manière correcte. Le cordon d'alimentation doit être correctement inséré dans la prise murale. Ne tirez pas sur le cordon d'alimentation d'une prise murale. Ne tirez pas sur le cordon d'alimentation d'une prise murale. Ne tirez pas sur le cordon d'alimentation d'une prise murale.
- Si l'appareil ne fonctionne pas normalement, arrêtez-le immédiatement et appelez un technicien qualifié pour le dépannage agréé.
- Entretien du boîtier.
 - Éteignez les composants avant de nettoyer l'appareil.