CROSLEY
FURNITURE

Entryway Tower
CF6025



PART LIST

A2 	B2 	C2 	D2 	E2 
Top Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Bottom Panel 1 PC	Fixed Shelf 1 PC
F2 	G2 	H2 	I2 	J2 
Back Panel 1 PC	Seat Panel 1 PC	Hook Slat 1 PC	Drawer Front Panel 1 PC	Drawer Left Panel 1 PC
K2 	L2 	M2 	N2 	
Drawer Right Panel 1 PC	Drawer Back Panel 1 PC	Drawer Bottom Panel 1 PC	Rail 2 PCS	

HARDWARE LIST

#1 Ø3*12mm	#2 Ø3*15mm	#3 Ø3.5*15mm	#4  Ø3*30mm	#5  Ø1/4"*1-1/4"
Short Screw 2 PCS	Round Head Screw 26 PCS (Extra 2)	Screw 8 PCS (Extra 1)	Long Screw 4 PCS	Bolt 10 PCS (Extra 1)
#6 Ø8*30mm	#7 	#8	#9  4mm	#10
Wood Dowel 28 PCS (Extra 2)	Handle 1 PC	Hook 4 PCS	Allen Wrench 1 PC	Safety Strap Kit 1 SET

ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.

 Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Please do not use tools to assemble this unit unless specifically indicated.



Reference the images above any time the instructions state "lock the hardware" or "insert hardware and pull down to lock".
Be sure to check all hardware is locked when complete.

Step 1. Attach handle (part #7) to drawer front panel (part I2) using short screws (part #1) and phillips head screwdriver. Attach drawer left panel (part J2) and drawer right panel (part K2) to drawer back panel (part L2) using wood dowels (part #6), long screws (part #4) and phillips head screwdriver. Slide drawer bottom panel (part M2) into grooves of assembled unit (parts J2, K2 & L2). Attach drawer front panel (part I2) to drawer panels (parts J2 & K2) using wood dowels (part #6) and lock the hardware.



Step 2. Attach hooks (part #8) to hook slat (part H2) using screws (part #3) and phillips head screwdriver.



#3 x 4

#8 x 2

Step 3. Attach hook (part #8) to left panel (part B2) using screws (part #3) and phillips head screwdriver.



#3 x 2

#8 x 1

Step 4. Attach hook (part #8) to right panel (part C2) using screws (part #3) and phillips head screwdriver.



#3 x 2
#8 x 1

Step 5. Attach top panel (part A2), fixed shelf (part E2), hook slat (part H2), seat panel (part G2) and bottom panel (part D2) to left panel (part B2) and right panel (part C2) using wood dowels (part #6), bolts (part #5), allen wrench (part #9) and lock the hardware.



#5 x 6
#6 x 20
#9 x 1

Step 6. Attach rails (part N2) to top panel (part A2) and bottom panel (part D2) using bolts (part #5) and allen wrench (part #9).



#5 x 4

#9 x 1

Step 7. Carefully turn unit upright. Attach back panel (part F2) to assembled unit (parts A2, B2, C2, D2, H2 & G2) using round head screws (part #2) and phillips head screwdriver.



#2 x 26

Step 8. Slide assembled drawer into place.

Note: To release trigger disconnect levers push one side up and the other down.

Important: safety strap kit (part #10) must be installed to prevent tipping, damage and/or injury.





#10	A	B	C	D	E
			D8*3/4"	D8*1-1/2"	
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Washer 2 PCS	Short Screw 1 PC	Long Screw 1 PC	Safety Wall Strap 1 PC

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) through washer (B) and safety wall strap (E) and attach to back panel (part F2) using phillips head screwdriver.

2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in back panel (part F2) where the safety wall strap (E) is attached. Tap wall anchor (A) into the hole.

3. Insert long screw (D) through washer (B) and safety wall strap (E) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.