
Sonos Ace Ultra




Overview

Sonos Ace Ultra is everything you want in your headphones. And then some.

- **Sonos sound.** Delivers Sonos' renowned sound deliver deep bass, clear detail, and balanced sound you can count on. Whether it's a podcast or the sound in real life based on how the headphones fit.
- **Tune the world.** Go to *to tune into Sonos Certified Home Theater Sound. Or hear what's around you with Sonos' Aware mode.
- **Battery that lasts and lasts.** Listen up to 30 hours with Adaptive Noise Cancellation on, or up to 42 hours with it off. Fast charge for 1 hour of playback.
- **Part of the Sonos system.** Play music, TV, and more by Sonos voice or touch from the Sonos app or to move wherever's playing from your speakers.
- **Designed for comfort.** Plush ear cushions, rotating ear cups, and an adjustable headband create a soft, supportive fit.

Controls, lights, and ports



1	Control Key	**Playback** • Play/Pause: Press once to pause or resume streaming content • Next Track: Press twice • Previous Track: Press three times **Volume**: Press up or down. Hold and hold to quickly change the volume **Voice** Press and hold to open your voice assistant, and hold to keep speak with recently compatible assistants.
2	Noise Control Noise Control	**Noise Control** How to switch between Active Noise Cancellation and Aware Mode. **Note**: In the Sonos app, you can change which Sonos Control options the button provides. **Voice Control** Press to activate the default voice device voice assistant, such as Siri or Sonos. You'll hear a tone when it's ready to talk. Indicates the battery, pairing state, Bluetooth connection, and regular product updates and errors. If turn off when you're wearing your headphones.
3	Status light	**Power on/off** • Press and hold about 2 seconds to power on your headphones. You'll hear a tone when they're ready to use. • Press and hold about 5 seconds to power off. You'll hear a tone as they power off. **Bluetooth pairing** • Press and hold about 7 seconds to put your headphones into Bluetooth pairing mode. Your headphones will remain discoverable for about 3 minutes. You'll hear a tone when they're ready to connect to Bluetooth devices. If unsuccessful, Sonos press the power button to switch between Bluetooth pairing and Bluetooth connected modes. **Factory reset** You can factory reset your Sonos Ace Ultra or one of the ingredients with the app, settings, and Bluetooth connections. Here's how: 1. Make sure your Sonos Ace Ultra is turned on. 2. Press and hold the Power/Bluetooth button. 3. When flashing, keep your Sonos Ace Ultra in the charging case. 4. The status light will flash white when your headphones have been factory reset. **Note**: Sonos Ace Ultra automatically resets to pair with Bluetooth devices when charged and after about a day of inactivity.
4	USB-C port	**Charging** Use the included cable to connect to USB-C certified or USB-PD compliant USB-C power supply. 1.5 W minimum (5 V/1.5A minimum). **Note**: • Fast charging your headphones lets an audio device to take: • USB-C to C or Lightning cable included. Suitable for charging headphones and devices without Lightning connectors. **Note**: Not compatible with third-party cables. • USB-C to USB-A cable. Suitable for charging headphones and devices without Lightning connectors. Bluetooth is disabled when Sonos Ace Ultra is connected to a device with a USB-C cable. The light will show solid white.

Adjust the fit

Sonos Ace Ultra headphones feature swing-away, with thoughtful considerations for different head shapes, head sizes, hairstyles, and accessories, to ensure comfort for as long as you're listening.

- Swing the ear cups to the left or right to adjust the fit. Sonos Ace Ultra headphones are the model of Sonos' first headphones with physical adjustments to support comfort and mobility on exceptional acoustic seal.
- To get the most out of your Sonos Ace Ultra, it's important that your headphones fit comfortably.
- Sonos Ace Ultra headphones are designed to fit a wide range of head sizes. Sonos recommends the model of the left ear cup is aligned with the outside of the left eye, and the right ear cup is aligned with the outside of the right eye. The ear cups should be able to be centered the left and right eyes.
- To find your Sonos Ace Ultra, they are designed to comfortably fit a wide range of head sizes. Sonos recommends the model of the left ear cup is aligned with the outside of the left eye, and the right ear cup is aligned with the outside of the right eye. The ear cups should be able to be centered the left and right eyes.

Ear cushion replacement

Ear cushions can be easily replaced if they wear out over time. Each cushion is securely held in place by magnets. Here's how to replace them:

- When installing the ear cushions, make sure Sonos Ace Ultra is turned off.
- Make sure both cushions are on the correct side. Look for the L (left) and the R (right).
- Before inserting a new cushion, clean the surface with a dry, lint-free cloth to remove dust and debris.
- The ear cushions will automatically snap into place.

Bluetooth connections

Sonos Ace Ultra headphones have built-in Bluetooth devices when unlicensed or after a factory reset.

- Sonos Ace Ultra headphones can be paired with up to eight Bluetooth devices, but only connect to one at a time. To start pairing mode by pressing and holding the Power/Bluetooth button on your headphones for about 7 seconds. Your headphones will remain discoverable for about 3 minutes. You'll hear a tone when they're ready to connect to Bluetooth devices.
- If you're pairing while streaming from Sonos Ace, hold the button past the power down sound (hold around until you hear a second tone) to enter pairing mode.
- If you're pairing while Sonos Ace is off and you're trying to turn on the headphones, hold the button for about 5 seconds.
- To connect a device you've already paired with, go to the device's Bluetooth settings and select your Sonos Ace Ultra headphones.
- If you're connecting while wearing Sonos Ace Ultra, you'll hear a sound confirming that your Sonos Ace Ultra headphones are connected.

Note: Sonos Ace Ultra headphones can't be connected to Bluetooth devices while in Sonos mode. Bluetooth settings will not show your headphones as "connected" in Sonos mode.

Light	Description
Solid white	Powered on, not connected to a Bluetooth device
Solid blue	Powered on, connected to a device via Bluetooth
Blinking blue	Powered on, searching for a Bluetooth device

Multipoint

Using Multipoint, you can connect your Sonos Ace Ultra to Bluetooth devices and automatically switch between them. Sonos Ace Ultra can be connected to up to eight devices at a time.

- Sonos automatically switches between devices you recently connected to. Quickly press the power button.
- **Note**: Multipoint is off by default. Turn it on in your Sonos Ace Ultra Settings.

Power and charging

Use the included cable to connect a USB-C certified or USB-PD compliant USB-C power supply. 1.5 W minimum (5 V/1.5A minimum).

While your Sonos Ace Ultra is charging, you can continue listening to a Bluetooth-connected device.

Note: To charge your Sonos Ace Ultra in a case, make sure the headphones are turned off.

Low battery

When the battery level reaches 10% power, you'll hear a tone and the status light will flash white.

Light	Description
Flashing white	Battery is low

Charging

Here's what to know about Sonos Ace Ultra's charging:

- The status light shows **solid orange** when your headphones are plugged in and charging.
- The status light will turn **solid green** when your headphones are plugged in and fully charged.

Light	Description
Solid orange	Plugged in and charging (normally, below 100% charge)
Solid green	100% battery. You can unplug your headphones
Flashing red	Charging error. Unplug your headphones from power

Rapid charging

Sonos Ace Ultra supports rapid charging. It's simple to listen. Apple charging quickly recharges them to give you 1 hour of playback in 3 minutes.

Use the included USB-C to USB-C cable and a compliant USB-C power supply (not included) to charge your headphones.

- 15 to 30 for 3 minutes.
- 50% to 100% over the next 3 hours.

Note: Rapid charging requires a room temperature between 50°F and 95°F (10°C to 35°C). Outside this range, your Sonos Ace Ultra charges at standard speed.

Linking to your system

You can link Sonos Ace Ultra to your system, and then use the Sonos app to control it there. You can also control your Sonos Ace Ultra headphones with the Sonos app when you're not wearing them. Here's how it works in more: to your headphones. Go to open Sonos Ace Ultra and touch to open settings.

- Go to the Sonos app for Sonos Ace Ultra for the rest of your system. Make sure your products are up to date and that you're connected to the same Wi-Fi network.
- Go to Settings then select your Sonos Ace Ultra.
- Touch to open Sonos. You will see any of the Sonos Ace Ultra apps with all compatible soundbars in your system.

Note: Linking to your system is a Sonos Ace Ultra feature, provided at no as, opt-in basis. It may change, be suspended, or be discontinued at any time without an notification by Sonos. You can turn it on or off in the Sonos app. additional terms may apply.

TV Audio Swap

TV Audio Swap allows you to move TV audio from a compatible Sonos soundbar to Sonos Ace Ultra. Set it up in the Sonos app. Here's how it works in more:

- Turn on your TV and connect your Sonos soundbar to your TV with an HDMI cable or headphone to make it. Here's the condition. Connect one end of Sonos Ace Ultra and one to open your Sonos app.
- Go to Settings then select your Sonos Ace Ultra. Touch to open Sonos Ace Ultra settings.
- Touch to open TV Audio Swap. Follow the instructions to connect your soundbar and headphones.

Voice control

Sonos Ace Ultra headphones have a microphone for voice control. Here's how it works:

- Press the Voice Control button. Available on the right ear cup. Press and hold to activate the voice assistant on your Sonos Ace Ultra headphones.

Wear detection

Sonos Ace Ultra wear detection is the way you're about if you're wearing them. When you take them off, Sonos Ace Ultra headphones pause your music or podcast.

Wear detection is on by default. With wear detection on, Sonos Ace Ultra will turn off after 30 minutes of inactivity. Turn on Sonos Ace Ultra Settings to see the wear detection and inactivity timeout options.

Note: If you take off Sonos Ace Ultra to hang around your neck, the self-continue out loud on your photosensitive device.

Phone calls

Microphones target your voice and suppress background noise to produce crystal clear audio during phone and video calls.

Answer a call

Press the Control Key once to answer an incoming call. You'll hear a tone when the call connects successfully.

Note: If you want to be able to turn on Voice Assistant to answer an incoming call automatically, turn on Auto Answer in the Voice Assistant settings of your Sonos Ace Ultra.

Decline a call

Press and hold the Control Key to decline an incoming call. You'll hear a tone when the call is declined.

End a call

Press the Control Key once to end an active call. You'll hear a tone when the call ends.

Product settings

Use the Sonos app to adjust product settings for Sonos Ace Ultra:

1. Go to **Settings** ⚙.
2. Choose Sonos Ace Ultra under **Headphones**.

Settings	Description
Name	Change the name of your Sonos Ace Ultra. The name will show up in Bluetooth pairing and the Sonos app.
Status	Displays battery percentage and time remaining.
Noise Control	Be provider 2 levels of Noise Control: • Active Noise Cancellation: Specifically reduces background noise. Make sure you're not aware of your surroundings when you're wearing your headphones. • Aware Mode: Sonos Ace Ultra uses its microphones to let in environmental sound so you can hear how your surroundings without removing your headphones. • Off: You can turn off Active Noise Cancellation and Aware Mode if Sonos is not useful or you're uncomfortable with environmental sound. Sonos Ace Ultra passively isolates you from background noise. **Noise Control Options** • Options: Active Noise Cancellation transition, reminds out your own voice so you can hear your voice when you're talking. Sonos Ace Ultra will automatically turn on Active Noise Cancellation on or off. Aware Mode will automatically turn on when you're talking and turn off when you're done. • Noise Boost: Increases the clarity of voices around you while you're in Aware Mode.
System	Make adjustments to **EQ**: • Bass • Treble • Balance **Loudness** **Low Power Tuning** on or off **Trial of Active Noise Cancellation** Select Processing with Dolby Head Tracking to turn on or off. Dolby Head Tracking is a feature that uses motion sensors to experience surrounds as if you're sitting in the middle of the room, regardless of the sound coming from around your head, and even if you turn. • **Spatial audio**: Turn on for Dolby Head Tracking. Turn on or off with compatible Spatial audio video content with your TV (or any other your head). So the sound is always coming from the direction of the screen, even if you turn your head. • **Head tracking**: Turn on for Dolby Head Tracking. Turn on or off with compatible Spatial audio video content with your TV (or any other your head). So the sound is always coming from the direction of the screen, even if you turn your head. • **Fixed Source**: Turned with TV Audio Swap. Turn on or off with compatible Spatial audio video content with your TV (or any other your head). So the sound is always coming from the direction of the screen, even if you turn your head. Sonos Ace Ultra headphones have built-in sensors. Sonos Audio Swap detects whether sound with your content.
Bluetooth	Manage multipoint, designated a preferred device, and add or remove connections to Bluetooth devices.
Battery	• **Charging**: Change how your headphones charge with Apple charging. • **Power Saving**: Change how your headphones turn battery off automatically saving mode due to customizable auto off times.
Hardware Controls	• **Noise Control**: Select the modes you want to cycle through when pressing the button on your Sonos Ace Ultra. • **Voice Control**: Select the voice assistant you want and answer calls when you press the button.
About	• Your product serial number • Check for software updates and see the current software version.

Specifications

Audio

Drivers	Custom-designed 40 mm dynamic drivers in each ear cup
Microphones	8 microphones for noise control and voice targeting
Spatial audio	Stream spatial audio content from supported services and devices
Loudness audio	Enjoy lossless audio over Bluetooth with a mobile device that supports aptX Adaptive, or about USB-C connection.
Noise control	Sonos Active Cancellation blocks external sounds. Aware mode blends ambient sound with your content.
Head tracking	Sonos Intelligent Battery Processing with Dolby Head Tracking. Enable this feature in the Sonos app.
TV Audio Swap	Press the Control Key to swap sound from a compatible Sonos soundbar to Sonos Ace Ultra (US and Mobile)
Adjustable EQ	Use the Sonos app to adjust bass, treble, and balance.

Details & Dimensions

Dimensions	• **Height**: 7.56 in (192 mm) • **Width**: 6.93 in (183 mm) • **Depth**: 3.15 in (80 mm)
Weight	0.73 lbs (331 g)
Colors	• Black • Soft White • Agave • Sand
Finishes	• Matte • Stainless steel • Vegan leather
UPC	Light on the bottom of the left ear cup indicates connection status.

Controls

Control Key	• **Slide up and down** for volume control • **Press once** to play/pause • **Press twice** to skip a track • **Press three times** to play previous track • **Press and hold** to activate a call • **Press and hold** to decline a call
Noise Control (right ear cup)	• Press to switch between Active Noise Control modes and your selected Aware Mode. • Press and hold to activate the voice assistant.
Power/Bluetooth (left ear cup)	• Press and hold the Power/Bluetooth button about 2 seconds to power on your headphones. • Press and hold the Power/Bluetooth button about 7 seconds to put your headphones into Bluetooth pairing mode. Your headphones will remain discoverable for about 3 minutes.

Power & Connectivity

Bluetooth	Bluetooth 5.3 supports audio streaming from any Bluetooth-enabled device
Battery (rated/tested)	Up to 30/42 hours (ANC on/off) and up to 42 hours of listening time (Bluetooth connection) with ANC off. Tested at 50% volume. **Standard**: Tested with all features including wireless to determine the unique charge method which you wear.
Charging	Use the included cable to connect a USB-C certified or USB-PD compliant USB-C power supply. 1.5 W minimum (5 V/1.5A minimum). Rapid charge (wireless): Sonos Ace Ultra supports fast or Qi wireless charging. Rapid charge (wireless): Sonos Ace Ultra supports fast or Qi wireless charging. Full charge from 0% can require up to 3 hours. • Rapid charge (wireless): Sonos Ace Ultra supports fast or Qi wireless charging. Rapid charge (wireless): Sonos Ace Ultra supports fast or Qi wireless charging. Full charge from 0% can require up to 3 hours. • Supports 802.3BC Qualcomm 2.0 (5 V/9
NFC	• Used to pay content from the app and easy with compatible speakers.
Operating temperature	32°F to 104°F (0°C to 40°C)
Charging temperature	32°F to 104°F (0°C to 40°C)
Rapid charging temperature	50°F to 95°F (10°C to 35°C)

What's in the box?

Product	Sonos Ace Ultra
Travel case	With removable cable pouch
USB-C to USB-C cable	1.5 m (5 ft)
USB-C to 3.5 mm cable	0.5 m (1.5 ft) **Note**: Sonos Ace Ultra is not compatible with third-party cables.
Documentation	Quickstart Guide and Supplementary information

Requirements

Audio source	Supported Bluetooth device, such as a smartphone
Power source	Use the included cable to connect a USB-C certified or USB-compliant USB-C power supply. 1.5 W minimum (5 V/1.5A minimum).

Important safety information

1. Read these instructions. Keep these instructions. Heed all warnings. Follow all instructions.
2. Clean only with dry cloth. Do not use with cloth with detergent. Household cleaners or solvents can damage the finish or your Sonos components.
3. Make sure that the USB-C socket and USB-C cable are dry before charging.
4. Do not block any fan hard sources such as radiators, heat registers, stoves, or other apparatuses that produce heat. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatuses (including amplifiers) that produce heat.
5. Protect the charging cable from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the product.
6. Only use attachments/accessories specified by the manufacturer. Use only with cart(s) listed. Use in conjunction with the cart, bracket, tripod, or table specified by the manufacturer, or sold with the apparatus.
7. Do not leave the product unattended during charging. Disconnect the device from power after charging is complete.
8. Refer all servicing to Sonos qualified service personnel.
9. Warning: The use of headphones or headsets at high volume for a long time can damage your hearing. Set the volume to a safe level and limit the amount of time you listen at high volume.
10. Do not use the product while cycling, driving, or engaged in any other activity where your full attention is required. Doing so may result in an accident.