Touch

Use the capacitive touch controls to play, pause, skip, replay, adjust the volume, turn off voice assistant, and group or ungroup Sonos products.

Bluetooth Button

Press to pair a Bluetooth device.

Mic Switch

Toggle off the switch on the back of the product to disconnect power to the microphones.