ASSEMBLY INSTRUCTION


DINING TABLE

1420T-3972

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person, this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.
4. Please do not fully tighten any screws or bolts until last step.
5. Periodically check to ensure that all connectores (bolts,screw,etc) are tight .

PRODUCTS LIST


No.	PART	DESCRIPTION	Q'TY
A		TABLE TOP	1
B		TABLE LEGS	2
C		CONNECTION PLATE	2

HARDWARE LIST


No.	PART	DESCRIPTION	Q'TY
1		BOLT Φ5/16"x35mm	24
2		LOCK WASHER Φ5/16"x13mm	24
3		FLAT WASHER Φ5/16"x19mm	24
4		ALLEN KEY M5 x 65mm	1

⚠ Only tighten all bolts when all bolts aligned with bolt inserts.


STEP 1:



STEP 2:



STEP 3: Completed



NOTE : Periodically check to ensure that all connectors (bolt, screws, etc.) are tight.