Content Key

Available in Early Access. Push and pull music between compatible Sonos products by pressing the Content Key. Control your headphones in the Sonos app when you are at home. Stream music over WiFi from your favorite music services and stations.

This feature is opt-in, as-is, subject to change during ongoing development. Requires a compatible Sonos speaker, WiFi, and the Sonos app.

Noise Control Button

On the right ear cup. Press to switch between Active Noise Cancellation and Aware mode. Long press to activate your voice assistant.

Power/Bluetooth Button

On the left ear cup. Press to power on and pair a device. Long press to pair additional devices. Double tap to switch between Bluetooth sources.