



STEP: 1

Open the drawers, unscrew the handle(s) from inside, install it on the outside, and tighten the screws.