

Step 1

ASSEMBLY INSTRUCTIONS

3900054-55

Albie KD Diamond Stitching PU Bar/ **Counter Stool**

| ITEM | PART | PICTURE | QTY | ITEM | PART | PICTURE | QTY |
|------|-----------|---------|-----|------|---------------|--|-----|
| 1 | Backrest | | 1 | Α | Bolt | 8x50 mm | 9 |
| 2 | Seat | | 1 | В | Spring washer | P | 9 |
| 3 | Front leg | | 1 | С | Flat washer | 0 | 9 |
| 4 | Foot Rest | | 2 | D | Screw | 80000000000000000000000000000000000000 | 4 |
| | | | | Е | Allen wrench | | 1 |

Flip the seat 2 upside down so that the bottom faces you. Remove the bottom fabric attached by velcro to get ready for assembly .

Flip front legs ③ and insert it into the seat ②. Fit a spring washer B to a bolt A followed by a flat washer C. Insert the bolt into a hole and tighten it with your hand until it is finger-tight. This will allow an opportunity to level the chair and prevent any unnecessary "rocking". Repeat this for the other hole and then





Step 2

Align the left and right rails 4 with the slots of front legs. Please identify each end of the foot rest carefully before aligning. Please pay attention on the sticker label on the foot rest to make sure foot rest in right position and they are attached in compliance with points below :1. The Straight Head of each foot rest goes into the slot of the front leg (as shown in Bird's Eye View). 2. The Angled Head of each foot rest shall incline outward (as shown in Bird's Eye View). 3. The screw holes on the foot rest face you (in the direction that would be toward the ground when standing upright). Please pay attention on the sticker label on the foot rest to



Step 3

Place the backrest ① on a level surface. Align the structure formed in Step 5 with the backrest. Fit the angled heads into the slots of the rear legs, Fit a spring washer C to a bolt B followed by a flat washer D. Insert the bolt into a hole on the seat frame and tighten it with your hand until it is finger-tight.



Step 4

Insert a screw D into a hole on the rail. Secure the screw in place using a screwdriver but do not tighten it yet. This will allow an opportunity to level the stool and prevent any unnecessary "rocking". Repeat this for the remaining screw holes.



Step 5

Place the loosely assembled stool in its desired location. Apply gentle downward pressure on the seat to eliminate rocking and ensure the stool is level. And then tighten all the screws and bolts

