

ASSEMBLY INSTRUCTIONS MANCHESTER COLLECTION S1128-BS Manchester 29" Bar Stool S1128-CS Manchester 24" Counter Stool

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts which may have come loose inside the carton during shipment. Identify, count all items and compare them with the PART LIST and HARDWARE LIST below.

CAUTION: Read the instructions carefully before assembly.

1. We recommend that you assemble this product with the assistance of another person to eliminate damage to the product during assembly.

- 2. Do not over-tighten the screws or bolts until the assembly is completed.
- 3. Keep all hardware parts out of reach of children.

4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

| | PARTS LIST | | | | HARDWARE | | | |
|-----|----------------|--------|------|-----|--------------------------|------------|-------|--|
| NO. | DESCRIPTION | SKETCH | QTY | NO. | DESCRIPTION | SKETCH | QTY | |
| A | BACKREST | | 1PC | 1 | SHORT BOLTS 1/4"x1" | | 4PCS | |
| В | SEAT | | 1PC | 2 | MEDIUM BOLTS 1/4"x1-3/4" | | 10PCS | |
| | SEAT | | IPC | 3 | LONG BOLTS 1/4"x2-1/8" | | 4PCS | |
| С | SEAT FRAME | | 1PC | 4 | SPRING WASHERS 1/4" DIA | \bigcirc | 18PCS | |
| D | ROUND FOOTREST | | 1PC | 5 | FLAT WASHERS 1/4" DIA | \bigcirc | 18PCS | |
| E | LEG | | 4PCS | 6 | ALLEN WRENCH 1/4" | | 1PC | |

<u>Step 1</u>

Step 2

Separate the hardware & store separately to prepare for assembly.

| SHORT BOLTS 1/4"x1" | | | |
|--------------------------|--|--|--|
| MEDIUM BOLTS 1/4"x1-3/4" | | | |
| LONG BOLTS 1/4"x2-1/8" | | | |

2

() X 4 () X 10

(*)

- FLAT WASHERS 1/4" DIA

SPRING WASHERS 1/4" DIA

⊖ X 18

O) X 18







MEDIUM BOLTS 1/4"x1-3/4"



ASSEMBLY INSTRUCTIONS MANCHESTER COLLECTION S1128-BS Manchester 29" Bar Stool S1128-CS Manchester 24" Counter Stool

| Step 4 2 MEDIUM BOLTS 1/4"x1-3/4" Immunitian 4 SPRING WASHERS 1/4" DIA Immunitian 5 FLAT WASHERS 1/4" DIA Immunitian | Step 5 2 MEDIUM BOLTS 1/4"x1-3/4" Immunitian 4 SPRING WASHERS 1/4" DIA Immunitian 5 FLAT WASHERS 1/4" DIA Immunitian |
|--|---|
| | |
| Step 6 | Step 7 2 MEDIUM BOLTS 1/4"x1-3/4" 4 SPRING WASHERS 1/4" DIA 5 FLAT WASHERS 1/4" DIA 0 0 0 0 0 0 0 0 0 0 0 0 0 |



ASSEMBLY INSTRUCTIONS MANCHESTER COLLECTION

S1128-BS Manchester 29" Bar Stool

S1128-CS Manchester 24" Counter Stool

<u>Step 8</u>

| 1 | SHORT BOLTS 1/4"x1" | |
|---|-------------------------|------------|
| 4 | SPRING WASHERS 1/4" DIA | \bigcirc |
| 5 | FLAT WASHERS 1/4" DIA | \bigcirc |

<u>Step 9</u>

Tighten all screws.



