Mission and Shaker Style Bed Assembly Instructions

Contents: sizes vary depending on model ordered

(A) = 1 headboard

(B) = 1 footboard

(C) = 2 bed rails (75" or 80" long)

(D) = 9 slats (twin = 40-1/4", double = 55-1/4" queen = 61-1/4" long)

(E) = 8 connector bolts (70mm long)

(F) = 8 cross dowels

(G) - 18 wood screws

(H) = 1 Allen key

Tools required:

Slotted screwdriver

#2 Robertson or Phillips screwdriver

(E) connector bolt (F) cross dowel (G) wood screw (H) Allen key









Please read all instructions before beginning

- 1. Assemble bed using 2 bed rails (C), 1 headboard (A), 1 footboard (B), 8 connector bolts (E), with 8 cross dowels (F). Refer to "Figure 1" for correct position of bed rail, bed end and hardware.
- Slide 9 slats (D) into bed rail grooves and secure each slat with 2 wood screws (G), using predrilled holes. Refer to "Figure 2". Position 1 slat 3" from each bed end and 7 evenly spaced in between.
 Ensure that the spaces between slats are less than 3 ½".







