

ASSEMBLY INSTRUCTION

ITEM: 6820-90267-80 6/0-6/6 Panel Headboard
 6820-90267-85 6/0-6/6 Panel Headboard
 6820-90267-99 6/0-6/6 Panel Headboard
 6820-90268-80 6/0-6/6 Panel Footboard
 6820-90268-85 6/0-6/6 Panel Footboard
 6820-90268-99 6/0-6/6 Panel Footboard
 6820-90251-80 5/0 Panel Headboard
 6820-90251-85 5/0 Panel Headboard
 6820-90251-99 5/0 Panel Headboard
 6820-90252-80 5/0 Panel Footboard
 6820-90252-85 5/0 Panel Footboard
 6820-90252-99 5/0 Panel Footboard
 6820-90253-80 5/0-6/6 Panel Rails
 6820-90253-85 5/0-6/6 Panel Rails
 6820-90253-99 5/0-6/6 Panel Rails
 6820-90263-80 6/0 Panel Rails
 6820-90263-85 6/0 Panel Rails
 6820-90263-99 6/0 Panel Rails

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK OF RAILS				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Threaded Rod	3/8*100mm	8 PCS
C		Curved Washer	ø3/8"	8 PCS
D		Nut	Ø3/8"	8 PCS
E		Open Wrench	Ø3/8"	1 PC

HARDWARE PACK OF FOOTBOARD				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
F		Screw	1 1/4"	16 PCS (For 5/0 Bed) 20 PCS (For 6/6 & 6/0 Beds)

PARTS LIST			
NO.	DRAWING	DESCRIPTION	Q'TY
1		Headboard	1 PC
2		Footboard	1 PC
3		Rail	2 PCS
4		Slat	4 PCS (For 5/0 Bed) 5 PCS (For 6/6 & 6/0 Beds)
5		Support Leg	4 PCS (For 5/0 Bed) 5 PCS (For 6/6 & 6/0 Beds)

Step 1: Attach Rails (3) to Headboard (1) and Footboard (2) by using Threaded Rods (A), Curved Washers (C) and Nuts (D), tighten them with Open Wrench (E) .

Step 2: Attach support legs (5) to slats (4).

Step 3: Attach slats (4) to the rails (3) and tighten them by using Phillips head screwdriver.

ASSEMBLY INSTRUCTION

ITEM: 6820-90267-80 6/0-6/6 Panel Headboard
6820-90267-85 6/0-6/6 Panel Headboard
6820-90267-99 6/0-6/6 Panel Headboard
6820-90268-80 6/0-6/6 Panel Footboard
6820-90268-85 6/0-6/6 Panel Footboard
6820-90268-99 6/0-6/6 Panel Footboard
6820-90251-80 5/0 Panel Headboard
6820-90251-85 5/0 Panel Headboard
6820-90251-99 5/0 Panel Headboard
6820-90252-80 5/0 Panel Footboard
6820-90252-85 5/0 Panel Footboard
6820-90252-99 5/0 Panel Footboard
6820-90253-80 5/0-6/6 Panel Rails
6820-90253-85 5/0-6/6 Panel Rails
6820-90253-99 5/0-6/6 Panel Rails
6820-90263-80 6/0 Panel Rails
6820-90263-85 6/0 Panel Rails
6820-90263-99 6/0 Panel Rails

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

