



SOCKET BUTTON HEAD
BOLT $\frac{5}{16}$ " X $1\frac{1}{2}$ "

WASHER
 $\frac{5}{16}$ "

INSERT NUT

LOCKNUT $\frac{1}{4}$ "

WASHER
 $\frac{1}{4}$ "

SOCKET BUTTON HEAD
BOLT $\frac{1}{4}$ " X $1\frac{1}{4}$ "

DESCRIPTION	#PZ
Socket Button Head Bolt $\frac{5}{16}$ " x $1\frac{1}{2}$ "	4
Socket Button Head Bolt $\frac{1}{4}$ " x $1\frac{1}{4}$ "	4
Washer $\frac{5}{16}$ " x $\frac{5}{8}$	4
Washer $\frac{1}{4}$ " x 1"	4
Locknut $\frac{1}{4}$ "	4
Allen Wrench $\frac{3}{16}$ "	1
Allen Wrench $\frac{3}{32}$ "	1

INSTRUCTIONS

- 1.- WITH SOME ONE ELSE'S HELP, PLACE THE TOP UPSIDE DOWN ON A FLAT AND CLEAN SURFACE.
- 2.- ALIGN THE HOLES IN THE LEGS WITH THE INSERT NUTS IN THE TOP, SCREW THE BOLTS WITHOUT TIGHTENING.
- 3.- PLACE THE SHELF THROUGH THE LEGS AND PUT THE BOLTS WITH THE PLAIN WASHERS AND LOCKNUTS AS SHOWN IN THE DIAGRAM.
- 4.- IF ALL THE PARTS ARE ALIGNED IN THEIR CORRECT POSITION, START TIGHTENING ALL THE COMPONENTS.



INTERNATIONAL
FURNITURE DIRECT, LLC

ASSEMBLING DIRECTIONS

I-BEN-E001

By:IFD

ITEM	DESCRIPTION	#PZ
1TOR005	Tornillo allen cab. Bola $\frac{3}{16}$ " x 1- $\frac{1}{2}$ " NEGRO	4
1TOR064	Tornillo Allen Cabeza Bola $\frac{1}{4}$ " X 1- $\frac{1}{4}$ " NEGRO	4
1RON005	Rondana Plana $\frac{3}{16}$ " x $\frac{3}{8}$ " GALV	4
1RON004	Rondana Plana $\frac{1}{4}$ " x 1" GALV	4
1TUER020	Tuerca de Seguridad $\frac{1}{4}$ " GALV	4
1HER251	Llave Allen $\frac{3}{16}$ " (mueble)	1
1HER250	Llave Allen $\frac{5}{32}$ " (mueble)	1