


Bookcase Bed Assembly Instructions

Contents:

- (A) 1 headboard (43" tall)
- (B) 1 footboard (16" tall)
- (C) 2 bed rails (80" or 85" long)
- (D) 9 slats (twin 40-1/4", full 55-1/4", queen 61-1/4" long)
- (E) 4 connector bolts (100mm long)
- (F) 4 cross dowels
- (G) 18 wood screws (1-1/2" long)
- (H) 4 wood screws (2-1/2" long)
- (I) 1 Allen key

Tools required:

- Slotted screwdriver
- #2 Robertson or Phillips screwdriver



Please read all instructions completely before beginning

1. Assemble the footboard (B) to each bed rail (C) using 4 connector bolts (E) with 4 cross dowels (F). Refer to Figure 1 for correct position of bed rail, bed end and hardware.
2. Position the bed rails into the headboard (A). Ensure that the bed rails are inserted as far as they will go.
3. Fasten the bed rails to the headboard with two 2 1/2" long wood screws (H) per bed rail through the pilot holes and into the headboard, refer to Figure 3.
4. Slide 9 slats (D) into bed rail grooves. Position so that the spaces between slats are equal. Secure each slat with two 1-1/2" long wood screws (G) using predrilled holes at each end of a slat, refer to Figure 2.

