Assembly Instructions For LADDER BACK SIDE CHAIR D.25263.SC

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

- 1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
- 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3. Please do not over tighten screws or bolts.
- 4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

| PART LIST FOR CHAIR | | | | | |
|---------------------|---|----------------|------|--|--|
| No. | PART DESC | CODE. | Q'TY | | |
| Α | SIDE CHAIR - BACK FRAME | PD.25263.SCBFR | 1 | | |
| В | SIDE CHAIR - SEAT FRAME W/CUSHION | PD.25263.SCSEA | 1 | | |
| С | SIDE CHAIR - LEFT & RIGHT FRONT LEGS | PD.25263.SCLEG | 2 | | |
| D | SIDE CHAIR - LEFT & RIGHT SIDE STRETCHERS | PD.25263.SCSTR | 2 | | |

| HARDWARE LIST PACKED INSIDE BOX | | | | | |
|---------------------------------|---------------|--------------------------|---------------|------|--|
| No. | HARDWARE DESC | | CODE. | Q'TY | |
| 1 | () () | ALLEN BOLT (1/4" x 40mm) | | 2 | |
| 2 | () () | ALLEN BOLT (1/4" x 60mm) | | 4 | |
| 3 | 9 | ALLEN BOLT (1/4" x 80mm) | | 4 | |
| 4 | Ø | SPRING WASHER (1/4") | PD.25263.SCHW | 10 | |
| 5 | 0 | FLAT WASHER (1/4") | | 10 | |
| 6 | (g) | SCREWS (M4x38mm) | | 4 | |
| 7 | | ALLEN KEY M4 | | 1 | |

