PROD. NO : DVT245024

Thank you for purchasing this quality product . Be sure to check all packaging material carefully for small parts that may have come loose inside the carton during shipment .

"Hardware is attached underneath the seat bottom"

This product will take 15-20 minutes to assemble

Components List :

NO	DESCRIPTION	SKETCH	QTY
А	Back Rest		1pc
В	Cushion Seat		1pc
С	Front Leg (Left)	II	1pc
D	Front Leg (Right)	20 0	1pc
Е	Side Stretcher (Left)		1pc
F	Side Stretcher (Right)		1pc
G	Front Stretcher		1pc

Hardware List :

NO	DESCRIPTION	SIZE	SKETCH	QTY
1	Allen Key	58x23x4 mm		1pc
2	Wrench	12x75 mm		1pc
3	Short Bolt	1/4" x38 mm		3pcs
4	Long Bolt	1/4" x85 mm		4pcs
5	Hex-Nut	5/16"		4pcs
6	Spring Washer	5/16" x Ø12	\bigcirc	11pcs
7	Flat Washer	5/16" x Ø19	\bigcirc	11pcs
8	Wood Screw	Ø8 x 50 mm	<i>⊲uuuuuu</i> _(}	6pcs

Screw driver is require for assembly (not included)

Reminders

1. Use only the hardware supplied.

2. Once the chair is finished, level and tighten all the bolts.

3. Do not over-tighten bolts.

4. This item may require periodic tightening.

NOTE :

1. Hardware pack is located underneath the Cushion Seat (B).

2. Two or more people are needed for assembly. Please keep all hardware

parts out of the reach of children.

1 OF 4

PROD. NO : DVT245024

 (\mathbf{B}) Grab hardware bag from underneath the Cushion Seat. Do not fully tighten bolts until the Product is level and the assembly of the product is completed. (\mathbf{A}) Fig.1 Step 1: Lay the Back Rest (A) on a flat soft surface such as a carpet and attach the Cushion Seat (B) to Back Rest (A) Using the provided hardware as shown in Fig. 1. (\mathbf{B}) Fig.2 Note: move seat back and forward to ease the finding of the hole in the corner block.

> Step 2 : Using the provided hardware attach the Cushion Seat (B) to Back Rest (A) as shown in Fig. 2 . Do not fully tighten bolts yet.

PROD. NO: DVT245024



PROD. NO: DVT245024



Step 6: Place the loosely assembled Barstool on a hard flat surface and apply gentle downward pressure on the seat. As shown on Fig.6. Once the Barstool is balanced and leveled, fully tighten all bolts.

Assembly is now Complete

4 OF 4