ASSEMBLY INSTRUCTIONS



BDIUSA.COM CUSTOMERSERVICE@BDIUSA.COM

Placement and Maintenance

OLA 8137 is designed for indoor use on level floors. Clean glass with glass cleaner, and wood veneer with a moist cloth.



Component List

OLA 8137 is engineered for easy assembly. Carefully follow this procedure to prevent any damage.

Unpack and identify the components. The assembly workspace should be a non-marring surface such as clean carpet. Use a blanket on the floor to protect cabinet during assembly.

For missing hardware pieces, please contact BDI Čustomer Śervice at customerservice@bdiusa.com.

For all other concerns, please contact your BDI Retailer.



Designed by Louis A. Lara These distinctive product configurations are protected by US and international patents, trade dress, and/or copyright laws. BDI are trademarks of Becker Designed, Inc. All Rights reserved. © 2011 BDI OLA 8137 Rev: 06-28-11

Step 1

With the help of another person, position the cabinet on it's back. Attach Metal Legs (F) to Cabinet (E) using Screws (C) and tighten with Hex Driver (A). Attach Wood Leg (G) to Cabinet (E) using Screws (D) and tighten with Hex Driver (A).



Step 2

Turn Cabinet Over and Install Back Panels With the help of another person, position the cabinet right side up. CAUTION: Do Not Turn Cabinet Over on the Doors. Install Back Panels (J) to the back side of the cabinet by inserting top edge in upper channel, then tipping bottom edge forward and into lower channel.





Step 3 Adjust Levelers as necessary 2 levelers for each **Metal Leg (F)** and 1 Leveler for **Wood Leg (G)**.







