

Lavatory Sink Overflow Assembly

NOTE: Install overflow before mounting lavatory sink into counter.

1. Remove overflow grill plug (A) from assembly, and mount thru hole in the side of the sink.

NOTE: Rubber gasket to be against underside of lavatory sink as illustrated.

2. Line up waste end (B) and waste opening. Insert waste fitting and install following the manufacturer's directions.

NOTE: Be sure rubber mack washer is positioned between lavatory sink and overflow fitting as illustrated.

3. Tighten overflow grill plug.
4. Tighten waste fitting.

