




- 1.- TURN THE SOFA UPSIDE DOWN ON A CLEAN AND FLAT SURFACE.
- 2.- ALIGN EACH LEG WITH THE HOLES AND SCREW THEM UNTIL THE LEGS ARE TIGHT.
- 3.- ONCE THE LEGS ARE INSTALLED, PLACE THE SOFA BACK TO ITS ORIGINAL POSITION.



ASSEMBLING INSTRUCTIONS

I-IUP-340

IUP340-ACH
IUP340-LOV
IUP340-SOF

ITEM #	DESCRIPTION	#
1	LEGS	4