


# ASSEMBLY INSTRUCTION

1841# BEDROOM

1841# MIRROR

LIST OF HARDWARE			QTY
	SCREWS	#8*1.2"	8PCS

1. Carefully place Mirror on the Dresser and line up center line.
2. Attach the two wooden Mirror supports to the Mirror and Dresser using the wood scrws provided.

