

# CON-QUEBED-KINBED-CALBED-013H/F/R/ CLASSIC CONTEMPORARY

**ASSEMBLY INSTRUCTIONS**

**TWO(2)PEOPLE REQUIRED**

**UNPACK ALL PARTS AND CHECK AGAINST PARTS LIST ON THIS INSTRUCTION SHEET BEFORE DISCARDING PACKING AND CARTONING!!**

- 1) Screw Bolts(F) into metal inserts in Headboard and Footboard finger-tight.
- 2) Connect the Headboard, Side Rails with Footboard by using Curved Washers , Flat Washers , Lock Washers and Nuts(A.B.C.D) . Use Wrench to tighten Nuts, as shown in Diagram A.
- 3) Assemble the Leg Supports to the Support Slats , as shown in Diagram B.
- 4) Mount the assembled support slats (done in step 4) onto the Side Rails with Screws (G).  
Use a Phillips Head Screwdriver to tighten screws, as shown in Diagram C.

\*\*\* NOTE KEEP THIS SHEET \*\*\*

In the unlikely event that you would need a replacement part for your furniture, please contact your local authorized Schnadig International dealer. If you need replacement hardware quickly, it could be purchased from your local hardware store.

RTA Hardware(7)			
NO.		Hardware List	Q'ty
A		Curved Washer(5/16"Dia)	8
B		Flat Washer(5/16"Dia)	8
C		Lock Washer	8
D		Nut	8
E		Wrench	1
F		Bolt	8

RTA Hardware(6)				
NO.		Hardware List	Q'ty(Queen bed)	Q'ty(Cal/King bed)
G		Screw(4.2x32)	12	16

Part Description	CON-QUEBED-013H/F/R Queen Bed		CON-KINBED-013H/F/R King Bed		CON-CALBED-013H/F/R Cal King bed	
	Part No.	QTY	Part No.	QTY	Part No.	QTY
Headboard (1)	CON-QUEBED-013HB	1	CON-KINBED-013HB	1	CON-KINBED-013HB	1
Footboard (2)	CON-QUEBED-013FB	1	CON-KINBED-013FB	1	CON-KINBED-013FB	1
Side rail (3)	CON-QUEBED-013RS	2	CON-KINBED-013RS	2	CON-CALBED-013RS	2
Slat(4)	CON-QUEBED-013FB-3067	3	CON-KINBED-013FB-3067	4	CON-KINBED-013FB-3067	4
Support leg (5)	CON-QUEBED-013FB-30305	3	CON-KINBED-013FB-30305	8	CON-KINBED-013FB-30305	8
RTA Hardware (6)	CON-QUEBED-013FB-3001	1	CON-KINBED-013FB-3001	1	CON-KINBED-013FB-3001	1
RTA Hardware (7)	CON-QUEBED-013RS-3001	1	CON-KINBED-013RS-3001	1	CON-QUEBED-013RS-3001	1

Created on:2013-09-13



