

Thank you for purchasing your heirloom quality furniture from Montana Woodworks<sup>®</sup>. Should you have any questions or need to contact sales or support, please do not hesitate to contact our corporate offices at 888.889.3728 or via E-Mail at: cs@montanawoodworks.com

Tools Needed: None

Before beginning assembly, please take a few moments to carefully read the instructions, familiarize yourself with the components and understand each step of the process. Likewise, please ensure that the hardware package contains the items as described below.

Parts List: (1) Headboard, (2) Drawer Sections, (2) Pieces of Plywood, (1) End Cap

Hardware List: None

Assembly Instructions:

Step 1. Layout all parts in a large, well lit area. DO NOT THROW AWAY THE TWO PIECES OF PLYWOOD!

Step 2. Stand headboard assembly upright.

**Step 3.** Place end cap assembly at the foot of the bed, separated from the headboard by the length of the drawer sections.

Step 4. Set drawer sections between the headboard and end cap with drawers facing outward.

**Step 5.** Raising the end of the drawer section, place the bracket into the corresponding hardware on the headboard.

Step 6. Repeat step 5 for opposite side.

Step 7. Insert end cap into pre-installed brackets on footboard end of cabinet sections.

**Step 8.** Place plywood on top of drawer sections. The plywood provides a mattress support foundation; a box spring is not necessary but may be used if desired.

PLEASE NOTE: If you purchased your item "ready to finish" special care must be taken to properly apply a high grade final finish in a timely manner. Doing so will help protect your purchase from discoloration and damage caused by exposure to ultra-violet light and/or weather. if the products intended use is outside, please use an exterior rated finish to also protect from weather damage. See use and care instructions for further information. Failure to adequately protect item by application and as needed, re-application of a final finish may void warranty.



