

ASSEMBLY INSTRUCTIONS

STYLE# 21265

Careful unpack all lamp parts from the carton.

1. Carefully remove all parts from the carton.
2. Be sure the power to the installation point is OFF.
3. Place the Fixture Body onto the Socket Assembly.
4. Determine the number of **Rods** to be assembled to the **Fixture Body** according to your hanging height. Pass supply wires through the **Rods**, thread the **Rods** onto the **Coupling** on the top of the **Fixture Body**, hand tighten until snug.
5. Attach one end of the **Quick Link** on the bottom of **Canopy**, and then attach the other end of the **Quick Link** onto the **Rods**.
6. Pass the supply wires through the **Ceiling Canopy** and the hole middle of the **Crossbar**.
7. Thread one **Hex Nut** onto the top end of the **Nipple**. Place one **Lock Washer** over the top end of the **Nipple** and then thread the **Nipple** into the center lock hole of the **Crossbar**. Then Using pliers, thread the **Hex Nut** against the **Crossbar** and hand tighten until snug.
8. Attach the **Ceiling Canopy** and the **Lock Washer** over the end of the **Nipple** and secure with the **Hex Nut**. Hand tighten until snug. Then Thread the **Lock Ball** onto the end of the **Nipple** and hand tighten until snug.
9. Place **Metal Shade** over the **Socket**, secure by thread the **Socket Collar** onto **Socket**. Hand tighten until snug.
10. Refer to label on socket and install proper wattage bulb. (Not Included)

Your installation is completed now. Restore electricity.
Retain this sheet for future reference !

