



INSTRUCTIONS:

1. WITH SOMEONE ELSE'S PLACE THE HEADBOARD IN FLAT SURFACE AND ALIGN THE LEGS.
2. THEN FIX BOTH LEGS AS SHOWN IN THE IMAGE "A" AND INSERT THE JOINT CONNECTOR IN THE HOLES.

NOTE. IF YOU SEE THAT WITH THE SCREWS THEY DO NOT TIGHTEN THE LEGS OF YOUR HEADBOARD, USE THE WASHER THAT ARE INCLUDE IN THE KIT, PLACE THEM ON THE BACK AS SHOWN IN FIG "A"

PRODUCT IMAGE SHOWN IS FOR ILLUSTRATIVE PURPOSES ONLY, SHOULD NOT BE TAKEN AS REFERENCE POINT

ASSEMBLY INSTRUCTIONS

UI-HBD-E001



HARDWARE

DESCRIPTION	#PCS
JOINT CONNECTOR BOLT 1/4 x 35 mm	8
JOINT CONNECTOR NUT 1/4 x 17 mm	8
LOCK WASHER 5/16"	8
WASHER 5/16"	8
KEY ALLEN 5/32	2