



- 1 Circular Knit Panel Ticking
- 2 Natural Chemical Free Fire Barrie
- 3 0.75" Super Soft Quilt Foam
- 4 3" High-density Convoluted Foarn
- 5 3" High-density Convoluted Foarn