


ASSEMBLY INSTRUCTIONS

X A HOWARD MILLER COMPANY

NO.	Hardware List		Q'ty
Α	(frame)	Bolt 5/16" * 1-25/32"L	4
В	(www.	Bolt 5/16" * 5-7/8"L	4
С	0	Lock Washer 5/16"Dia	8
D	0	Flat Washer 5/16" Dia	8
Е		Wrench 3/16"Dia* 4-3/4"L	1

7-9100 EXECUTIVE DESK



- 1. Place the top upside down on soft surface to prevent scratching, and rotate the bun feet to be tightened by hands.
- 2. Assemble the left & right pedistals and modesty panel with Bolt(A), Lock washer(C) and Flat washer(D) by using Wrench(E).
- 3. Place the top assembly on the pedestals. As shown in the side view the top assembly is set a little forward on the pedestals then pushed back to lock the french cleats.
- 4. Open the upper drawers in the pedestals.
- 5. Screw the top assembly and pedistals with Bolt(B), Lock washer(C) and Flat washer(D) by using Wrench(E).
- 6. Close the upper drawers.