

MODEL #

CM4193-E

Questions?

GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED



Allen Wrench




2 - Peopre Recommended

ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.





1 / 12






Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.


















Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.


Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY **INSTRUCTIONS**


Note :

Every cam lock bolt must have a cam lock connector in order to fasten the parts together.










Screw the cam bolt into panel.




Align the cam lock with its side opening (or arrow) pointing to cam bolt.


cam bolt

cam lock





Insert the cam bolt into the bolt hole of joint panel.



Turn the cam lock clockwise gently until it will not turn any more.

END TABLE


CM4193-E



 Please keep instructions for future reference.

• Check the quantity and irregularity of parts and hardware before you start.





END TABLE

CM4193-E



 Please keep instructions for future reference.

• Check the quantity and irregularity of parts and hardware before you start.



	HARDWARE	
#A 12pcs	#B12pcs	#C12pcs
ot the main second s		
Cam-Bolt 38mm	Cam-Lock Ø15mm	Wood Dowel 8 x 30mm
#D12pcs	#E12pcs	#F)4pcs
©M		
Short Bolt 1/4" x 9mm	Bolt 1/4" x 22mm	Felt Pad
#G1pc	#H 2pcs	#I)1pc
		S Minimum
Glue	Long Bolt 1/4" x 47mm	Screw 4 x 25mm
#J]1pc		

Allen Wench 4mm

