

MODEL#

CM7482-Q/K

Questions?

GIVE US CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PST)

TOOLS REQUIRED

Allen Wrench (Included) **Phillips**



(Not Included)




2 - Persons Recommended

ASSEMBLY RATING



EASY-DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.







Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline Toll-Free 1-888-980-5122



WEBSITE www.foagroup.com












Monday to Friday 8:30AM-5:30PM (PST)



E-MAIL cs.ec@foagroup.com



FurnitureOfAmerica



| Are you missing anything? | Check out our Quick Tips! |
|--|--|
| Double-check all parts, hardware and accessories listed on Page 6 are accounted for. | We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then! |
| Should we send any replacements? | Prep Time! |
| Are there any irregularities or flaws in the parts? We can send replacements! | Please review the assembly instructions and all diagrams prior to assembling. Set up your work- space by laying the parts and hardware our sepa- |

rately, then begin!

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or botto into their respective holes.



Use the appropriate hand bots of power tools for assembly. Select steps, such as tightening solews and/or bots, may require hand tools to avoid reusing damage during selection.



Turn electionise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later mantinance.




Mar two weeks, check and lighten any loose hardware and repeat again every six morths. thereafter.

IT IS THE QUIDT'S TOTERON THAT'S TO MAINTAIN THE ADMINISTRATION OF DAHOWARS MAY LOSSEN OVER THE AND MAY CAUSE THE BOT I HAD TO BE WORKEN AND SMADLE TO SUFFORT ITS STREET WHILLIT CAPACITY THE MAY I HAD THE LOSS AND MAY CAUSE BELLOIS IN A DT.

BED CM7482-Q/K



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

#1) x1pc



Headboard

#4) x 2pcs(L+R)



HB Columns



Upper Short Panels





Support Rail

#2x 1pc



Footboard





FB Columns



Slat (13pcs)



Leg

#3 x 2pcs



Side Rail





Upper Long Panels



Support leg

HARDWARE

#A) x 32pcs



Threaded Stud Ø5/16" x 3-1/8"





Hex Nut Ø5/16"x12MM





Power line

#B x 32pcs



Flat Washer Ø5/16"X 22MM





Screw M4X38MM

#0 x 32pcs




Spring Washer

#F) x 1pc



Wrench 12MM

Exploded View



CM7482-Q/K is packed in 4 cases


| Carton | Disignation | Part | | Hardware |
|------------|--------------------|------|-------------------------------|--------------|
| CM7482-1 | Headboard | #1 | | |
| | Footboard | #2 | | #A 32 PCS #B |
| | Side Rail | #3 | | |
| CM7482-2 | Slat (13pcs) | #8 | | |
| | Support leg | #9 | | |
| | Support Rail | #10 | | |
| | Leg | #11 | | |
| CM7482-3 | Upper Long Panels | #6 | | |
| OWN 402-3 | Upper Short Panels | #7 | | |
| CM7482-4 | HB Columns | #4 | ⟨पपपपपपपपपप | |
| OW17 402-4 | FB Columns | #5 | (परंप च पपपपप प ं) | |

1


Part #3 x2pcs (L+R)
Part #3 x2pcs (L+R)

Part #1) x4pcs

Twist on the leg (#11) to the HB and FB columns (#4,#5).



2




3

Part # x 1pc
Part x 2pcs (L+R)
Hardware A x 4pcs
Hardware B x 4pcs
Hardware C x 4pcs

Hardware #D x4pcs

Hardware #F)x1pc

Attach the Threaded stud (#A) to the HB Columns (#4). Align the HB Columns (#4) to the Headboard (#1) and secure by using Flat washer (#B), Spring washer (#C) and Hex nut (#D).



4

Part **②** x 1pc

Part **(43**) x 2pcs

Part #3 x 2pcs (L+R)

Hardware #A x12pcs


Hardware#Bx12pcs

Hardware #O x12pcs

Hardware Dx12pcs

Hardware#Fx1pc

4-1 Attach the Threaded stud (#A) to the FB Columns (#5). Align the FB Columns (#5) to the Footboard (#2) and secure by using Flat washer (#B), Spring washer (#C) and Hex nut (#D).



4-2 Align the Side rails (#2) to the Headboard and Footboard Columns (#4,#5) and secure by using the Threaded Stud (#A) with Flat washer (#B), Spring washer (#C) and Hex nut (#D).

5

Part # x 2pcs Part x 2pcs

Hardware #A x16pcs


Hardware (#B) x16pcs

Hardware #Ox16pcs

Hardware #D x16pcs


Hardware#F)x1pc


Attach the Threaded Stud (#A) to the HB and FB columns (#4,#5). Then align the the Upper long and Upper short panels (#6,#7) to the Columns and secure with Flat washer (#B), Spring washer (#C) and Hex nut (#D).




6

Part \$\mathbb{\text{4}} \text{x 1set} Part \$\mathbb{\text{4}} \text{x 8pcs} Part \$\mathbb{\text{4}} \text{0} \text{x2pcs} Align the Support rail (#10) onto the Slat (#8). Secure by twisting the Support leg (#9) through the Support rail (#10) and onto the Slat (#8).







This product is intended for RESIDENTIAL USE ONLY and not for commercial use.