

ASSEMBLY INSTRUCTION

ITEM: 6081-90867-82-6/0-6/6 Upholstered Headboard 6081-90868-82-6/0-6/6 Upholstered Footboard 6081-90863-82-6/0 Upholstered Rails

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK PART LIST

No.	Drawing	Description	Size	Q'ty
Α		All thread bolt	Ø5/16x4"	8
В		Half Round Washer Ø5/16"		8
С		Lock Washer Ø5/16"xØ14x1mm		8
D		Hexagon Nut	Ø5/16"	8
Е	(1)	Wood Screw Ø8x25mm		10
F		Wrench D12mm		1

No.	Drawing	Description	Q'ty
1		Headboard	1
2		Footboard	1
3		Side Rail	2
4		Slats	5
5		Slats Support	5

