

Model #100229-100393 (1742-650) King Side Rail & Slats • Model #100228-100391 (1742-660) King HB & FB Model #10229-100394 (1742-550) Queen Side Rail & Slats • Model #10228-100392 (1742-500) Queen HB & FB

Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly is required. The product of Hillsdale Furniture, LLC is designed for residential use only. Customer Service Phone Number: 502-562-0000





STEP 1

Begin assembly by connecting the Leg Extensions (M) to the Headboard (J) using 2 Allen Bolts (A) and 2 Flat Washers (C). See **Figure 1**.

STEP 2

Attach the Side Rails (L) to the Headboard (J) with 2 Allen Bolts (B), 2 Spring Washers (D) and 2 Flat Washers (C). See **Figure 2**.

STEP 3

Attach the Side Rails (L) to the Footboard (K) with 2 Allen Bolts (B), 2 Spring Washers (D) and 2 Flat Washers (C). See **Figure 3**.

STEP 4

Attach each Bottom Rail (H) to the Side Rails (L) with 1 Allen Bolt (B) and 1 Flat Washer (C) from the top and 1 Flat Washer (C) and 1 Hex Nut (E) from the bottom. See **Figure 4**. Tighten all bolts with the Allen Wrench (G) provided and the nuts with the Open Wrench (F) also provided.



Date: 10-15-2012 Page 2 of 2

 BAREMORE BED SET

 Model #100229-100393 (1742-650) King Side Rail & Slats • Model #100228-100391 (1742-660) King HB & FB

 Model #10229-100394 (1742-550) Queen Side Rail & Slats • Model #10228-100392 (1742-500) Queen HB & FB



CARE & MAINTENANCE: The touch of a soft cloth is all the maintenance the finish will ever need. Please do not use harsh or abrasive cleaners for polishing, as they may cause damage to the finish. Periodic checks are recommended to make sure that all bolts, screws and nuts are securely tightened.