

Assembly Instruction For

SQUARE BACK BARSTOOL

D-1710-8-BST1

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST			
No.	PART DESC	CODE.	Q'TY
A	BACK COUNTER	PD-1710-8-CBST1BAC	1
B	SEAT CUSHION WITH FRAME	PD-1710-8-CBSTSEA	1
C	LHF LEG FRAME	PD-1710-8-BSTLEG1	1
D	RHF LEG FRAME	PD-1710-8-BSTLEG2	1
E	BACK STRETCHER	PD-1710-8-CBSTSTR1	1
F	FRONT STRETCHER WITH METAL PLATE	PD-1710-8-CBSTSTR2	1

HARDWARE LIST			
NO.	HARDWARE DESC	CODE.	Q'TY
1	ALLEN BOLT (1/4" x 3-1/4")	PD-1710-8-CBTHW	4
2	ALLEN BOLT (1/4" x 1-3/4")		2
3	ALLEN BOLT (1/4" x 1-1/2")		4
4	SPRING WASHER (1/4")		8
5	FLAT WASHER (1/4" x 7/8")		8
6	WOOD SCREW (#8x 1-1/2")		4
7	WOOD SCREW (#8x 2")		2
8	NUTS		2
9	ALLEN KEY(M4)		1


⚠ Only tighten all bolts when all bolts aligned with bolt inserts.

STEP : 1




Assembly Instruction For
SQUARE BACK BARSTOOL
D-1710-8-BST1

STEP : 2



STEP : 3



COMPLETED

