

DECORATIVE

SSORIES

AND ACCENT FURNITURE

ASSEMBLY INSTRUCTIONS

STYLE# 21297

Carefully unpack all lamp parts from the carton.

- 1. Take the lamp carefully out of the Carton, and place it on a flat surface.
- 2. Be sure the power to the installation point is power off.
- 3.Determine the number of **rods** to be assembled to the **fixture body** according to your hanging height. Pass supply wires through the **rods**. Thread the **rods** onto the **nipple** on the top of the the **fixture body**. Hand tighten until snug.
- 4. Attach one end of the **quick link** on the bottom of **canopy**, then attach the other end of the **quick link** onto the **rods**.
- 5.Pass the supply wires through the ceiling canopy and the hole in the middle of the universal bar.
- 6.Place the **glass shade** carefully. Thread the **metal plate** and **metal sleave** onto the **socket**. Then lock the **socket collar** with the **plastic wrench** to secure the **shade**. Hand tighten until snug.
- 7.Install correct **bulbs** referring to fixture markings and/or labels for maximum wattage. (G45 Bulbs Included)



PO BOX 558/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151 www.uttermost.com