




Assembly Instructions

CM7200F/Q




ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY  DIFFICULT 

Tools Required for Assembly:

Allen Wrench



(Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY.
PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.

BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

MD


Parts List



#1 x 1 pc
Headboard




#2 x 2 pcs
Side Rail



#3 x 1 pc
Footboard




#4 x 1 pc
Support Rail



#5 x 4 pcs
HB/FB Foot




#6 x 26 pcs
Slat




#7 x 2 pcs
Support Rail Leg

Hardware List



#A x 8 pcs
Bolt 5/16"x1"



#B x 6 pcs
Bolt 5/16"x1-1/2"



#C x 8 pcs
Bolt 5/16"x4"



#D x 22 pcs
Lock Washer



#E x 22 pcs
Flat Washer



#F x 13 pcs
Center Connector



#G x 26 pcs
End Cap



#H x 1 pc
Allen Wrench




Due to the size and/or weight of this product, it is highly recommended that the assembly should be done near the area of its intended location. Make sure you have enough space to move around during the assembly. **ALWAYS** have at least two people to help with transporting and assembling the product to avoid any potential injury and/or damage.



- I. Align the two HB/FB feet (#5) with the pre-drilled holes underneath the headboard (#1).
- II. Prepare 4 bolt assemblies by inserting **FIRST** the lock washer (#D) onto the bolt (#C) and then the flat washer (#E) onto the **SAME** bolt (#C), in that order.
- III. Insert the bolt assemblies through the holes of the two HB/FB feet (#5) and secure those bolts using the Allen wrench (#H) to lock them with the headboard (#1).
- IV. Repeat the process above to assemble the remaining two HB/FB feet (#5) onto the footboard (#3).

#C x 8 pcs
#D x 8 pcs
#E x 8 pcs




Turn right (clockwise) to tighten



Turn right (clockwise) to tighten

#B x 2 pcs
#D x 2 pcs
#E x 2 pcs


- I. Align the 2 support rail legs (#7) with the pre-drilled holes of the support rail (#4).
- II. Prepare 2 bolt assemblies by inserting FIRST the lock washer (#D) onto the bolt (#B) and then the flat washer (#E) onto the SAME bolt (#B), in that order.
- III. Insert the bolt assemblies through the pre-drilled holes of the support rail (#4) using the Allen wrench (#H) to lock them with the 2 slat support legs (#7).



Adjust the levelers on the support rail legs (#7) according to the ground level on Step 4.




#A x 8 pcs
#D x 8 pcs
#E x 8 pcs



- I. Prepare 4 bolt assemblies by inserting FIRST the lock washer (#D) onto the bolt (#A) and then the flat washer (#E) onto the SAME bolt (#A), in that order.
- II. Insert the bolt assemblies through the right and left side of the pre-drilled holes of the headboard (#1) using the Allen wrench (#H) but expose about $\frac{1}{2}$ " of the bolts' threads.
- III. Mount the brackets on the side rails (#2) onto the bolts (#A) on each side of the headboard (#1). Make sure all the washers are in the FRONT of the brackets. Use the Allen wrench (#H) to further tighten the bolts to secure the two parts together.
- IV. Repeat the process above to assemble the other ends of the 2 side rails (#2) onto the footboard (#3).



#B x 4 pcs
#D x 4 pcs
#E x 4 pcs



Adjust the levelers according to the ground level. To lower or to raise the support rail legs, turn the levelers clockwise or counterclockwise, respectively.


- I. Align the assembled support rail (#4) with the pre-drilled holes on the center of the headboard (#1) and the footboard (#3). Prepare 4 bolt assemblies by inserting FIRST the lock washer (#D) onto the bolt (#B) and then the flat washer (#E) onto the SAME bolt (#B), in that order.
- II. Insert the bolt assemblies through the brackets of the support rail (#4) using the Allen wrench (#H) to lock them with the headboard (#1) and the footboard (#3).
- III.



Note: The correct position of the bed slats should be arcing UPWARD when placing on the rails.

#F x 13 pcs
#G x 26 pcs

- I. Prepare a bed slat using two slats (#6), one center connector (#F) and two end caps (#G). See diagram for the correct sequence in connecting those parts.
- II. Align the end caps (#G) with the pre-drilled holes on each side of the side rails (#2) and press firmly down on both end caps (#G) to lock with the side rails (#2). Then press firmly down on the center connector (#F) to lock with the support rail (#4).
- III. Repeat the process above to assemble the remaining bed slats onto the side rails (#2) and the support rail (#4).
- IV. Make sure the bed is rested on a flat surface and does not feel loose or wobbly. If it does, double check that the bolts/screws are secured and properly tightened.




ASSEMBLY IS COMPLETED



Furniture of America®

Assembly Instructions

CM7200CK/EK



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT

Tools Required for Assembly:

Allen Wrench




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.

BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.



Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

MD


Parts List



#1 x 1 pc
Headboard



#2 x 2 pcs
Side Rail



#3 x 1 pc
Footboard



#4 x 2 pcs
Support Rail



#5 x 4 pcs
HB/FB Foot



#6 x 39 pcs
Slat



#7x6pcs $\Phi 1/4"$
Support Leg-250x30x20mm

Hardware List



#A x 8 pcs
Bolt 5/16"x1"



#B x 14 pcs
Bolt 5/16"x1-1/2"



#C x 8 pcs
Bolt 5/16"x4"




#D x 30 pcs
Lock Washer




#E x 30 pcs
Flat Washer



#F x 26 pcs
Center Connector



#G x 26 pcs
End Cap



#H x 1 pc
Allen Wrench




Due to the size and/or weight of this product, it is highly recommended that the assembly should be done near the area of its intended location. Make sure you have enough space to move around during the assembly. **ALWAYS** have at least two people to help with transporting and assembling the product to avoid any potential injury and/or damage.



- I. Align the two HB/FB feet (#5) with the pre-drilled holes underneath the headboard (#1).
- II. Prepare 4 bolt assemblies by inserting **FIRST** the lock washer (#D) onto the bolt (#C) and then the flat washer (#E) onto the **SAME** bolt (#C), in that order.
- III. Insert the bolt assemblies through the holes of the two HB/FB feet (#5) and secure those bolts using the Allen wrench (#H) to lock them with the headboard (#1).
- IV. Repeat the process above to assemble the remaining two HB/FB feet (#5) onto the footboard (#3).

#C x 8 pcs
#D x 8 pcs
#E x 8 pcs




Turn right (clockwise) to tighten



Turn right (clockwise) to tighten

#B x 6 pcs
#D x 6 pcs
#E x 6 pcs


- I. Align the 3 support rail legs (#7) with the pre-drilled holes of the support rail (#4).
- II. Prepare 3 bolt assemblies by inserting FIRST the lock washer (#D) onto the bolt (#B) and then the flat washer (#E) onto the SAME bolt (#B), in that order.
- III. Insert the bolt assemblies through the pre-drilled holes of the support rail (#4) using the Allen wrench (#H) to lock them with the 3 slat support legs (#7).
- IV. Repeat the process above to assemble the remaining 3 support rail legs (#7) onto the other support rail (#4).




Adjust the levelers on the support rail legs (#7) according to the ground level on Step 4.



#A x 8 pcs
#D x 8 pcs
#E x 8 pcs



- I. Prepare 4 bolt assemblies by inserting FIRST the lock washer (#D) onto the bolt (#A) and then the flat washer (#E) onto the SAME bolt (#A), in that order.
- II. Insert the bolt assemblies through the right and left side of the pre-drilled holes of the headboard (#1) using the Allen wrench (#H) but expose about $\frac{1}{2}$ " of the bolts' threads.
- III. Mount the brackets on the side rails (#2) onto the bolts (#A) on each side of the headboard (#1). Make sure all the washers are in the FRONT of the brackets. Use the Allen wrench (#H) to further tighten the bolts to secure the two parts together.
- IV. Repeat the process above to assemble the other ends of the 2 side rails (#2) onto the footboard (#3).




Adjust the levelers according to the ground level. To lower or to raise the support rail legs, turn the levelers clockwise or counterclockwise, respectively.

- I. Align the two assembled support rails (#4) with the pre-drilled holes on the headboard (#1) and the footboard (#3).
- II. Prepare 8 bolt assemblies by inserting FIRST the lock washer (#D) onto the bolt (#B) and then the flat washer (#E) onto the SAME bolt (#B), in that order.
- III. Insert the bolt assemblies through the brackets of the two support rails (#4) using the Allen wrench (#H) to lock them with the headboard (#1) and the footboard (#3).



Note: The correct position of the bed slats should be arcing UPWARD when placing on the rails.

- I. Prepare a bed slat using 3 slats (#6), two center connectors (#F) and two end caps (#G). See diagram for the correct sequence in connecting those parts.
- II. Align the end caps (#G) with the pre-drilled holes on each side of the side rails (#2) and press firmly down on both end caps (#G) to lock with the side rails (#2). Then press firmly down on the two center connectors (#F) to lock with the two support rails (#4).
- III. Repeat the process above to assemble the remaining bed slats onto the side rails (#2) and the support rails (#4).
- IV. Make sure the bed is rested on a flat surface and does not feel loose or wobbly. If it does, double check that the bolts/screws are secured and properly tightened.




ASSEMBLY IS COMPLETED



ASSEMBLY INSTRUCTION

Furniture of America™

Item No:CM7200-T



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being relatively difficult). For some products, two persons are recommended.



DIFFICULT


Do not tighten screws until completely assembled.

PARTS IDENTIFICATION

NO	Part	Sketch	Quantity
1		HEAD BOARD	1PC
2		SIDE RAIL	2PCS
3		FOOT BOARD	1PC
4		FEET	4PCS
5		BED SLATS	13PCS


HARDWARE LIST

NO	Shape	Specification	Quantity
A		SCREW (M8x25mm)	8PCS
B		SCREW (M8x100mm)	8PCS
C		WASHER	16PCS
D		SPRING WASHER	16PCS
E		END CAP	26PCS
F		WRENCH	1PC



Do not tighten screws until completely assembled.

1. Buckle up (5) with plastic brackets (E) first.
2. The snap in both ends (E).



Do not tighten screws until completely assembled.