

- STEP 3 : Attach the Iron Angle at the Middle of Desk with Bolt (1), Washer(2) and Alen Key (5).
- STEP 4 : Tight the Iron Angle at the Middle with Screw (3), Small Washer(4) and Screw Driver (6)
- STEP 5 : Carefully turn the Industrial Desk upright