Tools Required: 8mm hex head socket.





Step 2: Press sleeper unit inwards to expose the connector bracket.



Step 3: Remove five (5) 8mm Hex screws per side.



Step 4: Pull sleeper mech out from bottom.



7/11/2016