
INSTALLATION INSTRUCTIONS

Equility™ (Formerly LYNDON®) Widespread Lavatory Faucet

Model D35109800




Thank you for selecting DXV. To ensure that your installation proceeds smoothly, please read these instructions carefully before you begin.

SAVE FOR FUTURE USE


RECOMMENDED TOOLS AND MATERIALS

Most of the procedures require the use of common tools and materials, which are available from hardware and plumbing supply stores. It is essential that the tools and materials be on hand before work is begun.



ROUGHING-IN DIMENSIONS:

• For reference



In the United States:

DXV
One Centennial Avenue
Piscataway, New Jersey 08855
Attention: Director of Customer Care

For residents of the United States, warranty information may also be obtained by calling the following toll free number: (800) 227-2734
www.DXV.com

In Canada:

DXV
5900 Avebury Road
Mississauga, Ontario
L5R 3M3
Canada

Toll Free: 1-800-387-0369
Local: 905-306-1093
Fax: 1-800-395-1498
www.DXV.ca

In Mexico:

DXV
Via Morelos 330
Col. Santa Clara Coatitla
Ecatepec, Estado de México 55540

Toll Free: 01-800-8391200
www.DXV.mx


Product names listed herein are trademarks of AS America, Inc.
© AS America, Inc. 2017

M965850 Rev. 1.0 (5/18)

1 SPOUT ASSEMBLY

CAUTION Turn off hot and cold water supplies before beginning.

- Insert SPOUT SHANK **(1)** through center hole of sink or mounting surface. Make sure RUBBER WASHER **(2)** is seated into groove in SPOUT ESCUTCHEON BASE **(3)**.
- Assemble RUBBER WASHER **(4)**, BRASS WASHER **(5)** and LOCKNUT **(6)** onto threads of SPOUT SHANK **(1)** from underside of lavatory or mounting surface.
- Align SPOUT **(7)** and tighten LOCKNUT **(6)**. Insert LIFT ROD **(8)** through SPOUT **(7)**.





2 REMOVE HANDLE ASSEMBLIES FROM VALVE BODIES

- Thread LOCKNUT **(1)** to bottom of VALVE BODY **(2)**. Make sure RUBBER WASHER **(3)** is installed. Insert VALVE BODY **(2)** through mounting hole from underside of lavatory or mounting surface.

Note: VALVE BODY marked Hot is installed in the left mounting. hole, VALVE BODY marked Cold in the right when facing front of fitting. Maximum mounting surface thickness is 1-1/4˝.

- From top install SPACER **(4)** and HANDLE **(6)** onto VALVE BODY **(2)**. Set VALVE BODIES **(2)** so that their outlets are facing toward SHANK **(5)** and then tighten LOCKNUT **(1)** using wrench or other approprite wrench to secure VALVE BODIES **(2)** to mounting surface.





3 INSTALL HANDLES AND SUPPLY HOSES


INSTALL HANDLES

- Turn VALVE STEMS **(1)** to off position. Align LEVERS **(2)** as shown or as desired and install HANDLE ASSEMBLY **(4)** onto VALVE STEM **(1)**.
- Thread HANDLE BASE **(3)** clock-wise onto VALVE BODY THREADS **(5a)** until seated tightly against mounting surface and aligned with the dotted line in the illustration.

INSTALL SUPPLY HOSES

- Thread supply hose COUPLING NUTS **(6)** onto outlets on VALVE BODIES **(5)**. Tighten with an adjustable wrench making a water tight connection.

Important: Loop SUPPLY HOSES (7) as illustrated so they do not kink.



M965850 Rev. 1.0 (5/18)


4 INSTALL POP-UP DRAIN

- Apply a bead of putty to underside of FLANGE **(1)**.




4a

- Drop FLANGE **(1)** into LAVATORY DRAIN **(2)**. From below assemble RUBBER GASKET **(3)**, METAL WASHER **(4)** and LOCK NUT **(5)**. Do not tighten.




4b

- Place SEAL **(1)** with small end facing up into TAILPIECE **(2)** and tighten against DRAIN BODY **(4)**. PIVOT ROD **(3)** opening in TAILPIECE **(2)** should face the rear of the lavatory. Tighten LOCK NUT **(5)** with channel locks.Do not over tighten.




4c

- Assemble PIVOT ROD **(1)**, PIVOT NUT **(2)**, CLIP **(3)** and SEAL **(4)** as shown. Hand tighten PIVOT NUT **(2)** Drop STOPPER **(5)** into drain. (For vandal proof drain rotate stopper so PIVOT ROD **(1)** goes through EYE (6) of STOPPER **(5)**. Make connection to "P" TRAP.
- Remove one end of CLIP **(3)** from PIVOT ROD **(1)** by squeezing ends together while sliding.
- Insert PIVOT ROD **(1)** into second or third hole in EXTENSION **(7)** and reassemble CLIP **(3)**. (EXTENSION **(7)** may need to be bent.)
- Adjust STOPPER **(5)** height by repositioning EXTENSION **(7)** and tightening THUMBSCREW **(8)**.



5 CONNECT DRAIN


- Connect 1-1/4" O.D. tailpiece on POP-UP DRAIN to waste outlet.



6 CHECK OPERATION OF POP-UP

- Operate LIFT KNOB **(1)** to verify that STOPPER **(2)** opens and closes.

Note: If STOPPER **(2)** does not open and close properly then refer to the "troubleshooting section" of these instructions.




M965850 Rev. 1.0 (5/18)

6 MAKE WATER SUPPLY AND WASTE CONNECTIONS


NOTE: FLEXIBLE SUPPLIES OR BULL-NOSE RISERS NOT INCLUDED AND MUST BE PURCHASED SEPARATELY.

- Connect water supply to VALVE BODIES **(1,1A)** with 1/2" IPS FLEXIBLE SUPPLIES **(2)** or 3/8" O.D. BULL-NOSE RISERS **(3)**. Use adjustable wrench to tighten connections. Do not over tighten. Be careful not to kink copper supply when bending. Use tubing cutter to cut to proper length.
- Connect HOT water supply to inlet of left SHANK and COLD water supply to right SHANK using sealant, appropriate connectors, and COUPLING NUTS.



7 TEST INSTALLED FITTING

- With HANDLE **(1)** in OFF position, turn on WATER SUPPLIES **(2)** and check all connections for leaks. ➡
- Remove AERATOR **(3)** using KEY **(6)**.
- Operate HANDLES **(1)** to flush water lines thoroughly.
- Replace AERATOR **(3)** and tighten.



8 CHECK DRAIN CONNECTIONS

- Operate POP-UP KNOB **(5)** and fill SINK with water. Check that DRAIN STOPPER **(4)** makes a good seal and retains water in Sink. If DRAIN STOPPER **(4)** does not seal properly, please refer to "Troubleshooting Guide" in these instructions.
- Push POP-UP KNOB **(5)** down and check all drain connections and "P" trap for leaks. ➡ Tighten if necessary.

M965850 Rev. 1.0 (5/18)

Equility™
(Formerly LYNDON®)
Widespread Lavatory Faucet

MODEL NUMBERS

D35109800

Replace the "YYY" with appropriate finish code

POLISHED CHROME	100
BRUSHED NICKEL	144
PLATINUM NICKEL	150
MATTE BLACK	243

