email: info@riverside-furniture.com

Prelude Home Office Assembly Instructions

Page 1 of 1

Made in Viet Nam

23930 **EXECUTIVE DESK**

Warning:

- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture must be assembled on a soft surface such as a blanket or carpet.

Components and Hardware List

STEP 1

Remove shipping brace by removing screws as shown. Discard the rail.

