## BERNHARDT


## EXTERIORS

## AVANNI SECTIONAL







 $\begin{array}{c} {\rm CORNER~CHAIR~O8032} \\ {\rm W~41.50~|~D~41.50~|~H~31.50~in.} \\ {\rm SH~15~|~SD~30.50~in.} \end{array}$ 





OTTOMAN 08031 W 41.50 | D 41.50 | H 16.50 in.




LEFT ARM CUDDLER O8034 W 63 | D 41.50 | H 31.50 in. SH 15 | AH 27.50 | SD 30.50 in.







$$\begin{split} & RIGHT\ ARM\ LOVESEAT\ O8041 \\ & W\ 65.50\ |\ D\ 41.50\ |\ H\ 31.50\ in. \\ & SH\ 15\ |\ AH\ 27.50\ |\ SD\ 30.50\ in. \end{split}$$



 $\begin{aligned} & \text{ARMLESS LOVESEAT 08040} \\ & \text{W 62} \; | \; \text{D 41.50} \; | \; \text{H 31.50 in.} \\ & \text{SH 15} \; | \; \text{SD 30.50 in.} \end{aligned}$